



Operation Manual for

EJ6910

TwinSAFE Logic Module

Version: 1.7.0
Date: 2017-11-15

BECKHOFF

Table of contents

1	Foreword	5
1.1	Notes on the documentation	5
1.2	Safety instructions	6
1.2.1	Delivery state	6
1.2.2	Operator's obligation to exercise diligence	6
1.2.3	Description of safety symbols	7
1.3	Documentation issue status	8
2	TwinSAFE System Description	9
2.1	Extension of the Beckhoff I/O system with safety functions	9
2.2	Safety concept	9
2.3	EtherCAT plug-in module system (EJ)	10
3	Product description	11
3.1	EJ6910 - TwinSAFE logic module	11
3.2	Intended use	11
3.3	Safety parameters	12
3.4	Technical data	13
3.5	Dimensions	14
4	Operation	15
4.1	Environmental conditions	15
4.2	Installation	15
4.2.1	Safety instructions	15
4.2.2	Transport / storage	15
4.2.3	Mechanical installation	15
4.2.4	Electrical installation	17
4.3	Configuration of the EJ6910 in TwinCAT	17
4.3.1	Configuration requirements	17
4.3.2	Adding an EJ6910	17
4.3.3	Address setting on the TwinSAFE EJ modules with 1023 possible addresses	19
4.3.4	Creating a safety project in TwinCAT 3	20
4.3.5	Downloading the safety application	47
4.3.6	Online Mode	50
4.3.7	New features in TC3.1 Build 4022	55
4.4	Info Data	71
4.4.1	Info data for the connection	71
4.4.2	Info data for function blocks	72
4.4.3	Info data for the TwinSAFE group	73
4.4.4	Info data for the device	74
4.5	Version history	75
4.6	User Administration	76
4.7	Backup/Restore	78
4.8	Export/import of the safety project	82
4.9	Tab Diag history	84
4.10	TwinSAFE SC configuration	85
4.11	Customizing / disabling TwinSAFE groups	89
4.12	Saving the analog group inputs persistently	92
4.13	Project design limits of EL6910/EJ6910	94
4.14	Sync-Manager Configuration	94

4.15	TwinSAFE reaction times	97
4.16	Diagnostics	99
4.16.1	Diagnostic LEDs.....	99
4.16.2	Status LEDs	101
4.16.3	Diagnostic objects	101
4.16.4	Cycle time of the safety project	102
4.17	Maintenance	103
4.18	Service life	103
4.19	Decommissioning	104
5	Appendix	105
5.1	Support and Service	105
5.2	Certificates	106

1 Foreword

1.1 Notes on the documentation

Intended audience

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the following notes and explanations are followed when installing and commissioning these components.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

Origin of the document

This documentation was originally written in German. All other languages are derived from the German original.

Currentness

Please check whether you are using the current and valid version of this document. The current version can be downloaded from the Beckhoff homepage at <http://www.beckhoff.com/english/download/twinsafe.htm>. In case of doubt, please contact Technical Support [► 105].

Product features

Only the product features specified in the current user documentation are valid. Further information given on the product pages of the Beckhoff homepage, in emails or in other publications is not authoritative.

Disclaimer

The documentation has been prepared with care. The products described are subject to cyclical revision. For that reason the documentation is not in every case checked for consistency with performance data, standards or other characteristics. We reserve the right to revise and change the documentation at any time and without prior announcement. No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

Trademarks

Beckhoff®, TwinCAT®, EtherCAT®, Safety over EtherCAT®, TwinSAFE®, XFC® and XTS® are registered trademarks of and licensed by Beckhoff Automation GmbH. Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents: EP1590927, EP1789857, DE102004044764, DE102007017835 with corresponding applications or registrations in various other countries.

The TwinCAT Technology is covered, including but not limited to the following patent applications and patents: EP0851348, US6167425 with corresponding applications or registrations in various other countries.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

Delivery conditions

In addition, the general delivery conditions of the company Beckhoff Automation GmbH & Co. KG apply.

1.2 Safety instructions

1.2.1 Delivery state

All the components are supplied in particular hardware and software configurations appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.






1.2.2 Operator's obligation to exercise diligence

The operator must ensure that

- the TwinSAFE products are only used as intended (see chapter Product description);
- the TwinSAFE products are only operated in sound condition and in working order.
- the TwinSAFE products are operated only by suitably qualified and authorized personnel.
- the personnel is instructed regularly about relevant occupational safety and environmental protection aspects, and is familiar with the operating instructions and in particular the safety instructions contained herein.
- the operating instructions are in good condition and complete, and always available for reference at the location where the TwinSAFE products are used.
- none of the safety and warning notes attached to the TwinSAFE products are removed, and all notes remain legible.

1.2.3 Description of safety symbols

In these operating instructions the following symbols are used with an accompanying safety instruction or note. The safety instructions must be read carefully and followed without fail!

 DANGER	Serious risk of injury! Failure to follow the safety instructions associated with this symbol directly endangers the life and health of persons.
 WARNING	Risk of injury! Failure to follow the safety instructions associated with this symbol endangers the life and health of persons.
 CAUTION	Personal injuries! Failure to follow the safety instructions associated with this symbol can lead to injuries to persons.
 Attention	Damage to the environment or devices Failure to follow the instructions associated with this symbol can lead to damage to the environment or equipment.
 Note	Tip or pointer This symbol indicates information that contributes to better understanding.

1.3 Documentation issue status

Version	Comment
1.7.0	<ul style="list-style-type: none"> • Project design limits updated • Description of new features in TwinCAT 3.1 Build 4022 added • Description temperature measurement updated • Intended use added
1.6.0	<ul style="list-style-type: none"> • Hint and flowchart to Backup/Restore added • Note to the input and output process image added • Description for Sync Manager configuration added • TwinSAFE SC description updated
1.5.1	<ul style="list-style-type: none"> • Screenshots User Administration updated • State and Diag of TwinSAFE group updated • Technical data <i>permissible air pressure</i> expanded
1.5.0	<ul style="list-style-type: none"> • Screenshots updated • Certificate updated
1.4.0	<ul style="list-style-type: none"> • Reference to standards updated • Safety parameters updated
1.3.0	<ul style="list-style-type: none"> • Description of diagnosis object 0xFEAO extended
1.2.0	<ul style="list-style-type: none"> • Description Backup/Restore expanded • Description TwinSAFE SC expanded
1.1.0	<ul style="list-style-type: none"> • Chapters External connections, FB port properties, Parameterization of the alias device, Variable mapping and Customizing updated
1.0.0	<ul style="list-style-type: none"> • Migration
0.6.0	<ul style="list-style-type: none"> • Preliminary (internal only)

2 TwinSAFE System Description

2.1 Extension of the Beckhoff I/O system with safety functions

The TwinSAFE products from Beckhoff enable convenient expansion of the Beckhoff I/O system with safety components, and integration of all the cabling for the safety circuit within the existing fieldbus cable. Safe signals can be mixed with standard signals as required. The transfer of safety-related TwinSAFE telegrams is handled by the standard controller. Maintenance is simplified significantly thanks to faster diagnosis and simple replacement of components.

The following basic functionalities are included in the TwinSAFE components: digital inputs (e.g. EL19xx, EP1908), digital outputs (e.g. EL29xx), drive components (e.g. AX5805) and logic units (e.g. EL6900, EL6910). For a large number of applications, the complete safety sensor and actuator technology can be wired on these components. The required logical link of the inputs and the outputs is handled by the EL69xx. In addition to Boolean operations, the EL6910 now also enables analog operations.

2.2 Safety concept

TwinSAFE: Safety and I/O technology in one system

- Extension of the familiar Beckhoff I/O system with TwinSAFE components
- Safe and non-safe components can be combined as required
- Logical link of the I/Os in the EL69xx TwinSAFE logic terminal
- Suitable for applications up to SIL 3 according to EN 61508:2010 and Cat 4, PL e according to DIN EN ISO 13849-1:2016-06
- Safety-relevant networking of machines via bus systems
- In the event of an error, all TwinSAFE components always switch to the wattless and therefore safe state
- No safety requirements for the higher-level standard TwinCAT system

Safety over EtherCAT protocol (FSOE)

- Transfer of safety-relevant data via any media ("genuine black channel")
- TwinSAFE communication via fieldbus systems such as EtherCAT, Lightbus, PROFIBUS, PROFINET or Ethernet
- IEC 61508:2010 SIL 3 compliant
- FSoE is IEC standard (IEC 61784-3-12) and ETG standard (ETG.5100)

Fail-safe principle (fail stop)

The basic rule for a safety system such as TwinSAFE is that failure of a part, a system component or the overall system must never lead to a dangerous condition. The safe state is always the switched off and wattless state.



CAUTION

Safe state

For all TwinSAFE components the safe state is always the switched-off, wattless state.

2.3 EtherCAT plug-in module system (EJ)

Similar to the EtherCAT terminal system, a module strand consists of a Bus Coupler and any desired I/O modules. In contrast to the EtherCAT Terminals, however, the EtherCAT plug-in modules have no spring-loaded contacts, since the wiring level is outsourced: communication, signal distribution and the supply of power to the modules takes place via plug connectors on the back side of the modules and the conductive tracks of the signal distribution board.

The EtherCAT plug-in modules and the plug level for sensors and actuators can be placed flexibly on the signal distribution board. Signal distribution boards can be user-developed or provided as custom solutions by Beckhoff Automation GmbH & Co. KG.




Fig. 1: EtherCAT plug-in module system (EJ)

3 Product description

3.1 EJ6910 - TwinSAFE logic module

The TwinSAFE logic EJ module is the link unit between the TwinSAFE input and output modules.

The EJ6910 module meets the requirements of IEC 61508:2010 SIL 3 and DIN EN ISO 13849-1:2016-06 (Cat 4, PL e).



Fig. 2: EJ6910 - TwinSAFE logic module

3.2 Intended use



WARNING

Caution - Risk of injury!

TwinSAFE EJ modules may only be used for the purposes described below!

The TwinSAFE EJ modules expand the application range of the Beckhoff EtherCAT system by functions that enable it to be used in the field of machine safety as well. The TwinSAFE EJ modules are designed for machine safety functions and directly associated to industrial automation tasks. It is therefore approved only for applications with a defined fail-safe state. This safe state is the wattless state.

The TwinSAFE EJ modules are suitable for operation on an EJ distribution board.



WARNING

System limits




The TÜV-SÜD certificate applies to the TwinSAFE EJ modules, the function blocks available in it, the documentation and the engineering tool. Approved engineering tools are *TwinCAT 3.1*, *TwinSAFE Loader* and *CODESYS Safety for EtherCAT Safety Module*. Any deviations from these procedures or tools, particularly externally generated xml files for TwinSAFE import or externally generated automatic project creation procedures, are not covered by the certificate.



WARNING

Power supply

An SELV/PELV power supply unit with a voltage limit of $U_{\max} = 36 \text{ V}_{\text{DC}}$ on the output side must be used to supply power for the TwinSAFE EJ modules with 24 V_{DC} . Failure to observe this can result in a loss of safety.

 WARNING	Commissioning test Before the TwinSAFE EJ modules can be used for the safety task, the user must carry out a commissioning test so that sensor and actuator wiring errors can be ruled out.
 CAUTION	Note the Machinery Directive The TwinSAFE EJ modules may only be used in machines according to the machinery directive.
 CAUTION	Ensure traceability The buyer has to ensure the traceability of the device via the serial number.

3.3 Safety parameters

Key figures	EJ6910
Lifetime [a]	20
Proof test Interval [a]	not required ¹⁾
PFH _D	1.81E-09
%SIL3 of PFH _D	1.81%
PFD _{avg}	2.56E-05
%SIL3 of PFD _{avg}	2.56%
MTTF _d	high
DC	high
Performance level	PL e
Category	4
HFT	1
Element classification ²⁾	Type B

1. Special proof tests over the whole service life of the EtherCAT EJ6910 module are not required.
2. Classification according to IEC 61508-2:2010 (see chapters 7.4.4.1.2 and 7.4.4.1.3)

The EtherCAT EJ6910 module can be used for safety-related applications as defined in IEC 61508:2010 up to SIL3 and DIN EN ISO 13849-1:2016-06 up to Cat 4, PL e.

For the calculation or estimation of the MTTF_d value from the PFH_D value, further information can be found in the TwinSAFE application manual or in DIN EN ISO 13849-1:2016-06 Table K.1.

3.4 Technical data

Product designation	EJ6910
Number of inputs	0
Number of outputs	0
Status display	4 diagnostic LEDs
Minimum/maximum cycle time	approx. 1 ms / according the project size
Error reaction time	≤ watchdog times
Watchdog time	Min. 2 ms, max. 60000 ms
Input process image	Dynamic, according to the TwinSAFE configuration in TwinCAT 3
Output process image	Dynamic, according to the TwinSAFE configuration in TwinCAT 3
Supply voltage (SELV/PELV)	24 V _{DC} (−15%/+20%)
Current consumption	approx. 222 mA
Power dissipation of the terminal	typically 1 W
Dimensions (W x H x D)	12mm x 66mm x 55mm
Weight	approx. 27 g
Permissible ambient temperature (operation)	−25°C to +55°C
Permissible ambient temperature (transport/storage)	−40°C to +70°C
Permissible air humidity	5% to 95%, non-condensing
Permissible air pressure (operation/storage/transport)	750 hPa to 1100 hPa (this corresponds to a height of approx. −690 m to 2450 m over sea level assuming an international standard atmosphere)
Climate category according to EN 60721-3-3	3K3 (the deviation from 3K3 is possible only with optimal environmental conditions and also applies only to the technical data which are specified differently in this documentation)
Permissible level of contamination according to EN 60664-1	level of contamination 2 (comply with the chapter Maintenance [► 103])
Impermissible operating conditions	TwinSAFE EJ modules must not be used under the following conditions: <ul style="list-style-type: none"> • under the influence of ionizing radiation (that exceeds the level of the natural environmental radiation) • in corrosive environments • in an environment that leads to unacceptable soiling of the Bus Terminal
Vibration/shock resistance	conforms to EN 60068-2-6 / EN 60068-2-27
EMC immunity/emission	conforms to EN 61000-6-2 / EN 61000-6-4
Shocks	15 g with pulse duration 11 ms in all three axes
Protection class	IP20
Permitted operating environment	control cabinet or terminal box with minimum protection class IP54 according to IEC 60529
Permissible installation position	see chapter Installation position and minimum distances [► 16]
Approvals	CE, TÜV SÜD

3.5 Dimensions






Fig. 3: EJ6910 - dimensions

Width: 12 mm
Height: 66 mm
Depth: 55 mm

4 Operation

4.1 Environmental conditions

Please ensure that the TwinSAFE components are only transported, stored and operated under the specified conditions (see technical data)!

 WARNING	<p>Risk of injury!</p> <p>The TwinSAFE components must not be used under the following operating conditions.</p> <ul style="list-style-type: none"> • under the influence of ionizing radiation (that exceeds the level of the natural environmental radiation) • in corrosive environments • in an environment that leads to unacceptable soiling of the TwinSAFE component
 Attention	<p>Electromagnetic compatibility</p> <p>The TwinSAFE components comply with the current standards on electromagnetic compatibility with regard to spurious radiation and immunity to interference in particular. However, in cases where devices such as mobile phones, radio equipment, transmitters or high-frequency systems that exceed the interference emissions limits specified in the standards are operated near TwinSAFE components, the function of the TwinSAFE components may be impaired.</p>


4.2 Installation

4.2.1 Safety instructions


Before installing and commissioning the TwinSAFE components please read the safety instructions in the foreword of this documentation.

4.2.2 Transport / storage

Use the original packaging in which the components were delivered for transporting and storing the TwinSAFE components.

 CAUTION	<p>Note the specified environmental conditions</p> <p>Please ensure that the digital TwinSAFE components are only transported and stored under the specified environmental conditions (see technical data).</p>
---	--

4.2.3 Mechanical installation

 DANGER	<p>Risk of injury!</p> <p>Bring the bus system into a safe, de-energized state before starting installation, disassembly or wiring of the devices!</p>
--	---

4.2.3.1 Control cabinet / terminal box

The TwinSAFE EJ modules must be installed in a control cabinet or terminal box with IP54 protection class according to IEC 60529 as a minimum.

4.2.3.2 Installation position and minimum distances

For the prescribed installation position the backplane is mounted horizontally (EJ plug connector vertical), and the connection surfaces of the EJ modules face forward (see diagram below). The EJ modules are ventilated from below, which enables optimum cooling of the electronics through convection. The direction indication “down” corresponds to the direction of positive acceleration due to gravity.




Fig. 4: Installation position and minimum distances

In order to ensure optimum convection cooling, the distances to neighboring devices and to control cabinet walls must not be smaller than those shown in the diagram.

4.2.3.3 Temperature measurement

The temperature measurement consists of an EJ1100 EtherCAT coupler, to which EJ modules are attached, based on the typical distribution of digital and analog signal types at a machine. On the EJ6910 a safety project is active, which reads safe inputs and enables safe outputs during the measurement.



Note

External heat sources / radiant heat / impaired convection

The maximum permissible ambient temperature of 55°C was checked with the sample configuration described above. Impaired convection; an unfavorable location near heat sources or an unfavorable configuration of the EtherCAT EJ modules may result in overheating of the modules.

The key parameter is always the maximum permitted internally measured temperature of 110°C, above which the TwinSAFE components switch to safe state and report an error. The internal temperature can be read from the TwinSAFE components via CoE.

4.2.4 Electrical installation



Risk of injury!

Bring the bus system into a safe, de-energized state before starting installation, disassembly or wiring of the devices!

4.2.4.1 Connections between EJ modules

The electrical connections between the EJ Bus Coupler and EJ modules are realized automatically by plugging the components into the EJ backplane.



Note

Note the maximum E-bus current!

Observe the maximum current that your EJ Bus Coupler can supply to the E-bus! Use the EJ9400 power supply module if the current consumption of your modules exceeds the maximum current your EJ Bus Coupler can provide.

4.2.4.2 Overvoltage protection

If protection against overvoltage is necessary in your plant, provide a surge filter for the voltage supply to the Bus Terminal blocks and the TwinSAFE EJ modules.

4.3 Configuration of the EJ6910 in TwinCAT



Do not change CoE objects!

Do not change any of the CoE objects in the TwinSAFE EJ modules. Changes in the CoE objects (e.g. via the System Manager or TwinCAT 3) permanently switch the TwinSAFE EJ modules to the *Fail-Stop* state or lead to unexpected behavior of the modules!

4.3.1 Configuration requirements

Configuration of the TwinCAT Safety PLC requires TwinCAT automation software version 3.1 build 4020 or higher. The current version is available for download from the Beckhoff website at www.beckhoff.de.



Note

TwinCAT support

The TwinCAT Safety PLC cannot be used under TwinCAT 2.

4.3.2 Adding an EJ6910

The EJ6910 TwinSAFE logic module is added in the same way as any other EtherCAT device. Open *Safety Terminals* in the list, then select the EJ6910 module.




Fig. 5: TwinCAT - adding an EJ6910

**Note****Size of the process image**

The process image of the EJ6910 TwinSAFE logic module is adjusted dynamically, according to TwinSAFE configuration created in TwinCAT 3.

4.3.3 Address setting on the TwinSAFE EJ modules with 1023 possible addresses



Fig. 6: Address setting on TwinSAFE EJ modules with 1023 possible addresses

Use the 10-way DIP switch on the left of a TwinSAFE EJ module to set the TwinSAFE address of the module. TwinSAFE addresses between 1 and 1023 are available.

DIP switch										Address
1	2	3	4	5	6	7	8	9	10	
ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	1
OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	2
ON	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	3
OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	4
ON	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	5
OFF	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	6
ON	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	7
...
ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	1023



WARNING

TwinSAFE address

Each TwinSAFE address may only be used once within a network / a configuration!
The address 0 is not a valid TwinSAFE address!

4.3.4 Creating a safety project in TwinCAT 3

4.3.4.1 Add new item

In TwinCAT 3 a new project can be created via *Add New Item...* in the context menu of the *Safety* node.




Fig. 7: Creating a safety project - Add New Item

The project name and the directory can be freely selected.




Fig. 8: Creating a safety project - project name and directory

4.3.4.2 TwinCAT Safety Project Wizard

In the TwinCAT Safety Project wizard you can then select the target system, the programming language, the author and the internal project name. Select the setting *Hardware Safety PLC* as the target system and the graphical editor as the programming language. The author and the internal project name can be freely selected by the user.




Fig. 9: TwinCAT Safety Project Wizard

4.3.4.3 Target System

Once the project has been created with the project wizard, the safety project can be assigned to the physical TwinSAFE module EJ6910 by selecting the *Target System* node.





Fig. 10: Selecting the Target System node

Set the target system to EJ6910 via the drop-down list and link it with the EJ6910 module via the Link button



next to *Physical Device*. If online ADS access to the terminal is possible, the software version, serial number, online project CRC and hardware address (DIP switch) are automatically read from the module. The DIP switch address must match the *Safe Address* set by the user.



Linking of target system and TwinSAFE module

4.3.4.4 Alias devices

The communication between the safety logic and the I/O level is realized via an alias level. At this alias level (subnode *Alias Devices*) corresponding alias devices are created for all safe inputs and outputs, and also for standard signal types. For the safe inputs and outputs, this can be done automatically via the I/O configuration.

The connection- and device-specific parameters are set via the alias devices.




Fig. 11: Starting the automatic import from the I/O configuration

If the automatic import is started from the I/O configuration, a selection dialog opens, in which the individual terminals, which are to be imported, are selected.




Fig. 12: Selection from the I/O tree

The alias devices are created in the safety project when the dialog is closed via OK.

Alternatively, the user can create the alias devices individually. To this end select *Add* and *New item* from the context menu, followed by the required device.




Fig. 13: Creating alias devices by the user

4.3.4.5 Parameterization of the alias device

The settings can be opened by double-clicking on the alias device in the safety project structure.





Fig. 14: Alias device in the safety project structure

The *Linking* tab contains the FSoE address, the checkbox for setting as *External Device* and the link to the physical I/O device. If an ADS online connection to the physical I/O device exists, the DIP switch setting is

displayed. Re-reading of the setting can be started via the button . The links to the EL6910/EJ6910 process image are displayed under *Full Name (input)* and *Full Name (output)*.









Linking	Connection	Safety Parameters	Process Image
FSoE Address: <input type="text" value="5"/>  Device is an external device: <input type="checkbox"/>			
Physical Device: <input type="text" value="TIID^Device 1 (EtherCAT)^Term 3 (EK1100)^Term 7 (EL1904)^M"/>  			
Dip Switch: <input type="text" value="5"/> 			
Full Name (input): <input type="text" value="TIID^Device 1 (EtherCAT)^Term 3 (EK1100)^Term 4 (EL6910)^C"/>  			
Full Name (output): <input type="text" value="TIID^Device 1 (EtherCAT)^Term 3 (EK1100)^Term 4 (EL6910)^C"/>  			

Fig. 15: Links to the EL6910/EJ6910 process image

The *Connection* tab shows the connection-specific parameters.







Linking	Connection	Safety Parameters	Process Image
Connection Settings			
Conn-No: <input type="text" value="2"/>  			
Conn-Id: <input type="text" value="3"/>  			
Mode: <input type="text" value="FSoE master"/>			
Watchdog: <input type="text" value="100"/>			
<input type="checkbox"/> Module Fault (Fail Safe Data) is COM ERR			
Connection Variables			
COM ERR Ack: <input type="text"/> 			
Info Data			
<input type="checkbox"/> Map State <input type="checkbox"/> Map Inputs			
<input type="checkbox"/> Map Diag <input type="checkbox"/> Map Outputs			

Fig. 16: Connection-specific parameters

Parameter	Description	User interaction required
Conn. no.	Connection number - automatically assigned by the TwinCAT system	No
Conn. ID	Connection ID: preallocated by the system, but can be changed by the user. A Conn ID must be unique within a configuration. Duplicate connection IDs result in an error message.	Control
Mode	FSoE master: The EL6910/EJ6910 is FSoE master for this device. FSoE slave: The EL6910/EJ6910 is FSoE slave for this device.	Control
Watchdog	Watchdog time for this connection. A ComError is generated, if the device fails to return a valid telegram to the EL6910/EJ6910 within the watchdog time.	Yes
Module Fault is ComError	This checkbox is used to specify the behavior in the event of an error. If the checkbox is ticked and a module error occurs on the alias device, this also leads to a connection error and therefore to switching off the TwinSAFE group, in which this connection is defined.	Yes
ComErrAck	If ComErrAck is linked with a variable, the connection must be reset via this signal in the event of a communication error.	Yes
Info data	The info data to be shown in the process image of the EL6910/EJ6910 can be defined via these checkboxes. Further information can be found in the documentation <i>TwinCAT function blocks for TwinSAFE logic terminals</i> .	Yes

The EL6910/EJ6910 support the activation of an ComErrAck at each connection. If this connection is linked after a communication disturbance in addition to the ErrAck of the TwinSAFE group also the respective

connection has to be set back via the ComErrAck signal. This signal is linked via the button  next to the **COM ERR Ack**. Via the following dialog the user can select an alias device. The signal can be cleared via the *clear* button within the *Map to* dialog.




Fig. 17: Selecting an alias device

The safety parameters matching the device are displayed under the *Safety Parameters* tab. They have to be set correctly to match the required performance level. Further information can be found in the TwinSAFE application manual.

Linking Connection Safety Parameters Process Image			
Index	Name	Value	Unit
8000:0	FS Operating Mode	>1<	
8000:01	Operating Mode	digital (0)	
8001:0	FS Sensor Test	>5<	
8001:01	Sensor test Channel 1 active	TRUE (1)	
8001:02	Sensor test Channel 2 active	TRUE (1)	
8001:03	Sensor test Channel 3 active	TRUE (1)	
8001:04	Sensor test Channel 4 active	TRUE (1)	
8002:0	FS Logic of Input pairs	>5<	
8002:01	Logic of Channel 1 and 2	single logic ch...	
8002:03	Logic of Channel 3 and 4	single logic ch...	

Fig. 18: Safety parameters of the device

4.3.4.6 Connection to AX5805/AX5806

There are separate dialogs for linking an AX5805 or AX5806 TwinSAFE Drive option card, which can be used to set the safety functions of the AX5000 safety drive options.

Creating and opening of an alias device for an AX5805 results in five tabs; the *Linking*, *Connection* and *Safety Parameters* tabs are identical to other alias devices.

Drive Option Card -...(2 axes, FW 5)_1.sds

Linking	Connection	Safety Parameters	General AX5805 Settings	Process Image
FSoE Address: <input type="text" value="1"/> Linking Mode: <input type="text" value="Automatic"/>				
Physical Device: <input type="text" value="TIID^Device 1 (EtherCAT)^Drive 5 (AX5206-0000-0203)^Term 6 ("/>				
Dip Switch: <input type="text" value="n.a."/>				
Full Name (input): <input type="text" value="TIID^Device 1 (EtherCAT)^Term 1 (EK1100)^Term 2 (EL6900)^C"/>				
Full Name (output): <input type="text" value="TIID^Device 1 (EtherCAT)^Term 1 (EK1100)^Term 2 (EL6900)^C"/>				

Fig. 19: AX5000 safety drive functions

The *General AX5805 Settings* tab can be used to set the motor string and the SMS and SMA functions for one or two axes, depending on the added alias device.




Fig. 20: AX5000 safety drive options - general AX5805 settings

The Process Image tab can be used to set the different safety functions for the AX5805.




Fig. 21: AX5000 safety drive options - Process Image

The parameters under the *General AX5805 Settings* and *Process Image* tabs are identical to the parameters under the *Safety Parameters* tab. Offers user-friendly display and editing of the parameters. The parameters under the *Safety Parameters* tab can also be edited.

The parameters for this function can be set by selecting a function in the inputs or outputs and pressing the *Edit* button. New safety functions can be added in the process image by selecting an empty field (---) and pressing *Edit*.

The parameter list corresponding to the safety function can be shown; in addition, an optional diagram of the function can be shown. At present the diagram is still static and does not show the currently selected values.




Fig. 22: AX5000 safety drive options - Function Diagram

4.3.4.7 External connection

An external custom FSoE connection can be created for a connection to a further EL69x0, EJ6910, KL6904 or a third-party device. If an own ESI file exists for a third-party device, this device will be listed as an selectable safety device and the choice *Custom FSoE Connection* is not needed.




Fig. 23: Creating an external connection (Custom FSoE Connection)

Before the connection can be used and linked further, the process image size must be parameterized. This can be set under the *Process Image* tab. Suitable data types for different numbers of safety data are provided in the dropdown lists for the input and output parameters.




Fig. 24: Parameterization of the process image size

When the size is selected, the individual signals within the telegram can be renamed, so that a corresponding plain text is displayed when these signals are used in the logic. If the signals are not renamed, the default name is shown in the editor (Safe Data Byte 0[0], ...).





Fig. 25: Renaming the individual signals within the telegram

The connection is linked under the *Linking* tab. The Link button  next to *Full Name (input)* and *Full Name (output)* can be used to select the corresponding variable.




Fig. 26: Selecting the variable

This can be a PLC variable, for sample, which is then forwarded to the remote device or can be linked directly with the process image of an EtherCAT Terminal (e.g. EL69x0 or EL6695).




Fig. 27: Direct linking with the process image of an EtherCAT Terminal

Further information can be found in the TwinCAT documentation for the variable selection dialog.

The *Connection* tab is used to set the connection-specific parameters.




Fig. 28: Connection-specific parameters

Detailed information about the individual settings can be found in the following table.

Parameter	Description	User interaction required
Conn. no.	Connection number: is automatically assigned by the TwinCAT system	No
Conn. ID	Connection ID: preallocated by the system, but can be changed by the user. A Conn ID must be unique within a configuration. Duplicate connection IDs result in an error message.	Control
Mode	FSOE master: The EL6910/EJ6910 is FSOE master for this device. FSOE slave: The EL6910/EJ6910 is FSOE slave for this device.	Control
Type	None: Setting for third-party equipment, for which no ESI file is available. KL6904: Setting for KL6904 (safety parameter inactive) EL69XX: Setting for EL6900/EL6930/EL6910/EJ6910 (safety parameter inactive)	Yes
Watchdog	Watchdog time for this connection: A ComError is generated, if the device fails to return a valid telegram to the EL6910/EJ6910 within the watchdog time.	Yes
Module Fault is ComError	This checkbox is used to specify the behavior in the event of an error. If the checkbox is ticked and a module error occurs on the alias device, this also leads to a connection error and therefore to switching off the TwinSAFE group, in which this connection is defined.	Yes
Safe Parameters (Appl. Param)	Device-specific parameters: The parameter length is automatically calculated from the number of characters that is entered. This information will typically be provided by the device manufacturer.	Yes
ComErrAck	If ComErrAck is linked with a variable, the connection must be reset via this signal in the event of a communication error.	Yes
Info data	The info data to be shown in the process image of the EL6910/EJ6910 can be defined via these checkboxes. Further information can be found in the documentation <i>TwinCAT function blocks for TwinSAFE logic terminals</i> .	Yes

4.3.4.8 Creating the safety application

The safety application is realized in the sal worksheet pertaining to the TwinSAFE group (sal - **Safety Application Language**).

The toolbox provides all the function blocks available on the EL6910/EJ6910.




Fig. 29: Function blocks available for EL6910/EJ6910

The function blocks can be moved from the toolbox into the sal worksheet via drag and drop. Variables can be created by clicking next to a function block input or output, which can then be linked with alias devices in the *Variable Mapping* dialog.





Fig. 30: Function block on the sal worksheet

Once the pointer connector  **Pointer** has been selected from the toolbox, connections between the input and output ports of the function blocks can be dragged with the mouse.




Fig. 31: Dragging a connection between two function blocks




Fig. 32: Connection between two function blocks

4.3.4.9 Networks

For structuring the safety application, several networks can be created within a sal worksheet. Right-click in the worksheet and select *Add After* and *Network* or *Add Before* and *Network* to create a network after or before the current network.




Fig. 33: Creating a network

The instance path to the FB port to be linked can be specified, in order to exchange signals between the networks. The instance path consists of the network name, the FB name and the FB port, each separated by a dot. The input of the instance path is case-sensitive.

<Network name>.<FB name>.<FB port name>

Sample: Network1.FBStop1.EStopIn3

Alternatively, *Change Link* can be selected by opening the context menus next to the FB port.




Fig. 34: Change Link

This function opens a dialog for selecting a suitable FB port.




Fig. 35: Dialog for selecting a suitable FB port

Once the link has been created on one side of the connection, the link is automatically set/displayed on the opposite side.




Fig. 36: Link display

4.3.4.10 TwinSAFE groups

It makes sense to create TwinSAFE groups in cases where different machine safety zones are to realize, or simply in order to separate the fault behavior. Within a group, a FB or connection error (here: alias device) leads to a group error and therefore to switching off all outputs for this group. If an error output of an FB is set, it will be forwarded as a logical 1 signal.

A group can be created by opening the context menu of the safety project and selecting *Add and New Item....*




Fig. 37: Creating a TwinSAFE group

Like the first group, the group of a subitem for the alias devices and a sal worksheet.




Fig. 38: Components of the TwinSAFE group

The instance path to the FB port to be linked can be specified, in order to exchange signals between the groups. The instance path consists of the group name, the FB name and the FB port, each separated by a dot. The input of the instance path is case-sensitive.

<group name>.<network name>.<FB name>.<FB port name>

Sample: TwinSafeGroup1.Network1.FBStop1.EStopIn3

Alternatively, *Change Link* can be selected by opening the context menus next to the FB port.




Fig. 39: Change Link

This function opens a dialog for selecting a suitable FB port.




Fig. 40: Dialog for selecting a suitable FB port

Once the link has been created on one side of the connection, the link is automatically set/displayed on the opposite side.




Fig. 41: Link display

4.3.4.11 Variables of the TwinSAFE group

The inputs and outputs of the TwinSAFE groups are consolidated under the *Group Ports* tab of the *Variable Mapping* dialog.



Note

EL6910 group inputs

For a project to be valid, as a minimum the signals *Run/Stop* and *ErrAck* must be linked.




Fig. 42: The Variable Mapping dialog

Group Port	Direction	Description
Err Ack	IN	Error Acknowledge for resetting errors within the group - Signal must be linked with a standard variable
Run/Stop	IN	1 - Run; 0 - Stop - Signal must be linked with a standard variable
Module Fault	IN	Input for an error output of another connected module, e.g. for EK1960
Com Err	OUT	Communication error in one of the connections
FB Err	OUT	Error at one of the FBs used
Out Err	OUT	not used
Other Err	OUT	ModuleFault OR AnalogValueFault OR WaitComTimeoutFault
Com Startup	OUT	At least one of the connections of this group is in startup
FB Deactive	OUT	The group was deactivated. (See also section Customizing / disabling TwinSAFE groups [► 89])
FB Run	OUT	FBs of the TwinSAFE group are processed
In Run	OUT	TwinSAFE group is in RUN state

Group State

Value	Status	Description
1	RUN	Input RUN=1, no error in the group, and all connections have started up without error
2	STOP	Input RUN = 0
4	ERROR	Group is in error, see Diagnostic information
5	RESET	After an error has occurred, all errors have been rectified and the Err Ack signal is 1
6	START	The group remains in this state as long as not all connections have started up after the start of the group (RUN=1)
7	STOPERROR	When the group is started or initialized, it assumes the STOPERROR status if the TwinSAFE connections are assigned to the group. The group switches from STOPERROR state into ERROR state if the Run input is TRUE.
16	DEACTIVE	Group was deactivated via customizing
17	WAITCOMERROR	This state is set when the customizing function "Passivate" is selected and the system waits for ComError of the group

Group Diag

Value	Status	Description
0	-	No error
1	FBERROR	at least one FB is in ERROR state
2	COMERROR	at least one connection is faulty
3	MODULEERROR	the input ModuleFault is 1
4	CMPEERROR	On startup, at least one analog FB input deviates from the last saved value (Power-On Analog Value Check Error)
5	DEACTIVATEERROR	In "passivate manual control unit" mode the timeout has elapsed while waiting for the COM error
6	RESTARTERROR	The TwinSAFE Logic program was restarted because the EtherCAT connection was restarted or a user login was performed, without e.g. the TwinSAFE Logic program (or parts of it) has been reloaded.

4.3.4.12 Order of the TwinSAFE groups

The order of the groups can be changed, in order to realize a defined processing sequence of the safety application.

To this end, select the entry *Edit TwinSAFE Group Order* via the node menu of the safety project node. A dialog opens, in which the order of the groups can be changed. The individual groups do not necessarily have to be numbered in consecutive ascending order. The numbering can contain gaps.




Fig. 43: Context menu Edit TwinSAFE Group Order

The current group order is shown in the column *Current Value*. The new order is specified by entering a value in the column *New Value*, followed by OK.




Fig. 44: Dialog Change Execution Order of TwinSAFE Groups

4.3.4.13 Command line

The *command line* below the SAL worksheet can be used to enter commands for executing functions.




Fig. 45: The command line below the SAL worksheet

Currently the commands listed in the following table are supported.

Command	Description
FBNAME FB_INSTANCENAME NETWORKNAME;	Adding a function block Sample: safeAnd FBAnd1 Network1
FB_INSTANCENAME->PORTNAME = VARIABLE_NAME;	Creating a variable mapping Sample: FBAnd1->AndIn1 = testVariable
FB_INSTANCENAME->PORTNAME = FB_INSTANCENAME->PORTNAME;	Creating a connection between two FBs Sample: FBAnd1->AndIn1 = FBO1->OrOut;

4.3.4.14 FB port properties

The behavior of the inputs can be parameterized by opening the properties for the upper input of an input pair or an individual input of the function block. For an input group, such as the function block ESTOP, the individual inputs to be activated or deactivated, and single- or two-channel evaluation can be set.




Fig. 46: FB port properties

Channel interface	Description
Both deactivated	Both inputs deactivated
Single-Channel 1 Activated	channel 1: single channel evaluation channel 2: deactivated
Single-Channel 2 Activated	channel 1: deactivated channel 2: single channel evaluation
Single-Channel Both Activated	channel 1: single channel evaluation channel 2: single channel evaluation
Two-Channel	Both inputs activated and two channel evaluation with <i>discrepancy time (ms)</i>

If the *Two-Channel* evaluation is enabled, the corresponding *Discrepancy time (ms)* can be set in milliseconds. For each input there is a setting to indicate whether the input should be evaluated as *Break Contact (NC)* or *Make Contact (NO)*. When a variable or a connecting line is connected to the function block, the corresponding channel is enabled automatically.




Fig. 47: Make Contact (NO) / Break Contact (NC) setting

These settings are also accessible for each individual port of an FB via the context menu *Change InPort Settings*.




Fig. 48: Menu Change Inport Settings





Fig. 49: Dialog Change InPort Settings

4.3.4.15 Variable Mapping

Variable Mapping						
Variables						
Assigned Variable	Direction	Alias Port	Port Name	Instance Name	Function Name	
EStop_In_1	input	Term 7 (EL1904) - Module 1 (FSOES).InputChannel1 (TwinSafeGroup1)	EStopIn1	FBESop1	safeEstop	
EStop_In_2	input		EStopIn2	FBESop1	safeEstop	
Restart	input	RestartForEstop.In (TwinSafeGroup1)	Restart	FBESop1	safeEstop	
EDM_Signal	input		EDM1	FBESop1	safeEstop	
Output	output		EStopOut	FBESop1	safeEstop	

Fig. 50: Variable Mapping

Variables are linked to the alias devices in the *Variable Mapping* window. Use the Link button  to open the selection dialog for the alias port. Safe only signal types or safe and standard signal types are offered in the selection dialog automatically, depending on the port setting of the FB. Safe boolean signals are shown with a yellow background, standard signal types with a white background.

If several outputs should be set by one variable, these signals can be dedicated by holding the CTRL key and selecting the channels.




Fig. 51: Selection dialog for the alias port

4.3.4.16 Safety toolbars

Once the development of the safety project is complete, the project has to be loaded onto the target system, in this case EL6910. To this end the toolbars *TwinCAT Safety* and *TwinCAT Safety CRC* have to be added.










Fig. 52: Activation of the TwinCAT Safety and TwinCAT Safety CRC toolbars








Fig. 53: Display of the TwinCAT Safety and TwinCAT Safety CRC toolbars

Toolbar TwinCAT Safety

Icon	Name	Description
	Verify Safety Project	The safety project is checked for validity.
	Verify Complete Safety Project	The safety project including the hardware level is checked for validity.
	Download Safety Project	Loading the safety project onto the target system, here EL6910
	Delete Safety Project	Deleting the safety project from the target system, here EL6910
	Show Online Data of Safety Project	Switching on the online display for the safety project.
	Customize Safety Project	Customizing the safety project (switching off TwinSAFE groups and setting of safe substitute values for the group outputs). This is possible if online and offline CRC are the same and at least one group has been configured for customizing..

Toolbar TwinCAT Safety CRC

Icon	Name	Description
	CRC Toolbar	Left-click on the toolbar to initiate an update of the CRCs by the user. Red icon: CRCs are different
	CRC Toolbar	Green icon: All CRCs are identical
	Online CRC	CRC of the safety project on the EL6910. This value is read online by the terminal. In the absence of an ADS connection to the EL6910, this value is displayed with 0x----.
	Downloaded CRC	CRC of the safety project that was loaded last. If no safety project is loaded when the TwinCAT project is opened, the value is displayed with 0x----.
	Offline CRC	CRC of the current safety project, as stored in the safety editor. A CRC is displayed, if the stored project is valid. If the project is invalid, 0x---- is displayed as CRC.

4.3.4.17 Checking the TwinSAFE addresses

The hardware addresses of the alias devices used can be checked and set via the dialog *Check Safe Addresses*.

To this end, select the entry *Check Safe Addresses* via the node menu of the safety project node. A dialog opens, which lists all alias devices that use hardware addresses. The addresses set in the software (*Safe/FSoE Address*) and the hardware addresses (*Hardware Address*) are shown in separate columns for each alias device and for the target system. In the column *Take Hardware Address* the user can specify whether the hardware addresses for the alias devices settings are applied when the dialog is closed via the *OK* button.




Fig. 54: Check Safe Addresses context menu









Fig. 55: Check Safe Addresses dialog

4.3.5 Downloading the safety application

Before downloading the safety project onto the EL6910/EJ6910 or EK1960, check the project for validity. If the hardware is complete, the hardware level  can be used for checking, or checking can take place at the project level , if online access is only available for the EL6910/EJ6910 or EK1960. If the check returns no errors, the project download  can continue.

 CAUTION	Use only qualified tools Only use a qualified tool (see note on system limits) for loading, verifying and enabling the project on the EL6910/EJ6910 or EK1960!
 Note	User name and password are case-sensitive Pay attention to upper/lower case characters for the user name and password. The standard user is <i>Administrator</i> , the standard password is <i>TwinSAFE</i> .

**Attention****Power supply during download**

Please assure that the power supply for the TwinSAFE logic is not switch off during download. This can cause unexpected behavior or shut down the TwinSAFE Logic permanently.

**WARNING****Execution of the safety application**

The execution of the current project on the TwinSAFE logic is stopped during a logon or the download of a safety application.

The screenshot shows the 'Download Project Data' dialog box with the 'Login' step selected in the 'Steps' pane. The 'Login' section contains three input fields: 'Username:' with the value 'Administrator', 'Serial Number:' with the value '00123456', and 'Password:' with masked characters (dots). At the bottom right are 'Next' and 'Cancel' buttons.

Fig. 56: Download Project Data – The Login dialog

In the *Download Project Data* dialog specify the user name, the serial number of the EL6910/EJ6910 or EK1960 onto which the project is to be loaded, and the user password. The default user name is *Administrator*, the default-password is *TwinSAFE*. Use the *Next* button to move to the next dialog.

The screenshot shows the 'Download Project Data' dialog box with the 'Select Project Data' step selected in the 'Steps' pane. The 'Select Project Data' section contains a 'Select Data:' label and a dropdown menu. The dropdown menu is open, showing a list of options: 'Complete Project Data' (highlighted), 'Safe Logic Data', 'Mapping Data', 'Parameter Data', and 'Info Data'. At the bottom right are 'Next' and 'Cancel' buttons.

Fig. 57: Download Project Data – The Select Project Data dialog

In the *Select Project Data* dialog select *Complete Project Data* to load the whole project onto the EL6910/EJ6910 or EK1960. Use the *Next* button to move to the next dialog.




Fig. 58: Download Project Data – The Download Result dialog

Once the download is complete, the download results are displayed. Use the *Next* button to move to the next dialog.




Fig. 59: Download Project Data – The Final Verification dialog

The locally calculated CRCs and the online CRCs of the safety project are displayed in the *Final Verification* dialog. They are automatically checked for equality and displayed via the column *Verification Result*. The user must also check these data for equality and then confirm this by ticking the checkbox. Use the *Next* button to move to the next dialog.

Fig. 60: Download Project Data – The Activation dialog

In the *Activation* dialog the user re-enters the password to activate the safety project on the EL6910/EJ6910 or EK1960. Use the *Finish* button to complete the download of the safety project.

**WARNING****Verification of the input and output process data**

After downloading the safety-related program to the TwinSAFE logic, the user must check that the input and output process data of the TwinSAFE logic are plausible, within the valid value range and in the expected magnitude. This is especially true for analog signals, which are transmitted via e.g. PROFIsafe, FSoE sensors, TwinSAFE SC terminals or external control systems to the TwinSAFE logic. It is particularly important to check whether the device uses the Motorola or the Intel format or Big or Little Endian.

Project data	Description
Safe Logic Data	Safe Logic Data contains the safety related application.
Mapping Data	Mapping Data contains the link data for inputs, outputs, function blocks, connections etc.
Parameter Data	Parameter Data contains the safe user parameters that are to be stored at the TwinSAFE Logic. This could be safe substitute values and the user parameters of the connections.
Info Data	Info Data contains the settings which Info Data for connections, function blocks, groups etc. are activated and have to be filled by the TwinSAFE Logic.

**Note****Info Data of the safety project**

The Info Data will NOT take effect to the calculation of the project CRC. Because of this the Info Data could be changed later without changing the project CRC. After changing the Info Data of an existing project, a project download of minimum the Input Data has to be done even of same Project CRC, otherwise it won't be filled. Additional the TwinCAT configuration has to be activated, so that the size of the process image in Twin-CAT fits to the expected size within the TwinCAT Logic.

4.3.6 Online Mode

In Online mode  the current values of the safety project are displayed. A green color change indicates logical 1 within the SAL worksheet and the variable mapping. No color change means logical 0.




Fig. 61: SAL worksheet and variable mapping in online mode

On each function block the current FB state is shown as text and in the form of an icon. The different states are listed in the FB documentation. The following table describes the icons.

FB Icon	Description
	FB State: RUN In RUN state no error is present, and the output of the FB is set.
	FB State: SAFE In SAFE state no error is present, and the output of the FB is NOT set.
	FB State: ERROR/STOP In ERROR/STOP state an FB error is present or the FB is still in STOP state. This is the case if the group has not yet been started.

In addition, the online display can be extended by displaying analog and digital values. To this end the function can be enabled or disabled by selecting *Show Online Values* from the context menu in the SAL worksheet.




Fig. 62: Activation of Show Online Values

In online mode the analog and digital values are then displayed as text next to the respective variables.




Fig. 63: Display of the analog and digital values in online mode

Detailed information about the whole safety project is shown on the *Safety Project Online View* tab. Any errors in the connections or function blocks are displayed in plain text.

Safety Project Online View	
Name	Value
<ul style="list-style-type: none"> <ul style="list-style-type: none"> TwinSafeGroup1 <ul style="list-style-type: none"> State Diag Inputs <ul style="list-style-type: none"> RUN Error Acknowledgement Outputs <ul style="list-style-type: none"> Fb Err Com Err Other Err Alias Devices <ul style="list-style-type: none"> Term 5 (EL2904) - Module 1 (FSOES) <ul style="list-style-type: none"> State Diag <ul style="list-style-type: none"> xxxx 0000₂ 1xxx xxxx₂ Term 7 (EL1904) - Module 1 (FSOES) <ul style="list-style-type: none"> State Diag <ul style="list-style-type: none"> xxxx 0000₂ 1xxx xxxx₂ Function Blocks <ul style="list-style-type: none"> FBStop1 (safeEstop) <ul style="list-style-type: none"> State Diag <ul style="list-style-type: none"> xxxx xxxx xxx1 xxxx₂ 	State: ERROR (0/2 connections not running, 1/1 functions blocks in error) 0x04 (ERROR) 0x01 (00000001 ₂), FB Error 1 0 1 0 0 Conn-Name: Message_2, Conn-No: 1 0x68 (Data) 0x80 (10000000 ₂) No Diagnosis info Master reports Failsafe Value active Conn-Name: Message_3, Conn-No: 2 0x68 (Data) 0x80 (10000000 ₂) No Diagnosis info Master reports Failsafe Value active 0x04 (ERROR) 0x0010 (0000000000010000 ₂) EDM monitoring error EDM1
Safety Project Online View Variable Mapping Error List Output	

Fig. 64: The Safety Project Online View tab

4.3.7 New features in TC3.1 Build 4022

In the TwinCAT Version 3.1 Build 4022 some extensions have been implemented for the TwinSAFE editor. With the release of the TwinCAT version, these are available to the user. This chapter lists the new features.

4.3.7.1 Group status

The status of the TwinSAFE group is displayed as a color-coded frame in online mode.

The RUN state is marked with a green one, the ERROR state with a red frame, and all other states with a blue frame.




Fig. 65: Group Status Online RUN




Fig. 66: Group Status Online ERROR




Fig. 67: Group Status Online STOP

4.3.7.2 Online view group ports

In online mode the group inputs and outputs are marked according to their signal status. A logical 1 of the signal is represented with a green background, a logical 0 with a white background. Error information is displayed with a red background.

Variable Mapping				
Variables	Group Ports	Replacement Values	Max Start Deviation	
Group Port	Online Value	Direction	Alias Port	
Err Ack	False	input	ErrAck.In (TwinSafeGroup1)	
Run/Stop	True	input	Run.In (TwinSafeGroup1)	
Module Fault	False	input		
Com Err	True	output		
FB Err	True	output		
Other Err	False	output		
Com Startup	False	output		
FB Deactive	False	output		
FB Run	True	output		
In Run	False	output		

Variable Mapping

Fig. 68: Online View Group Ports

4.3.7.3 Group templates

The user has the choice between 3 templates.

The templates differ by the number of already existing links (none, ErrAck created and linked to group port, ErrAck and Run created and linked to group ports).




Fig. 69: Templates for Safety Projects

4.3.7.4 Networks collapsable

The networks defined in a TwinSAFE group can be collapsed.




Fig. 70: Collapsing of networks

4.3.7.5 Subfolder Alias Devices

Under the node *Alias Devices*, further subfolders can be created. After the subfolder has been created, it can be renamed, here for example to *Drives*.




Fig. 71: Adding a subfolder

After adding a subfolder, *Alias Devices* can be added in this folder.




Fig. 72: Subfolder e.g. Drives

4.3.7.6 Goto linked element

The entry *Goto Linked Element* can be called via the context menu. All links and variables used on that port are listed. By selecting an entry, you jump to the appropriate location in the network, TwinSAFE group or variable mapping.




Fig. 73: Goto Linked Element

4.3.7.7 Path view to linked signal

The *Linking* tab of the *Alias Devices* displays the links to the PLC and to the I/O devices. The name in the process image of the TwinSAFE logic is displayed under the entry *Name*.




Fig. 74: Path view for safety Alias Devices

For the *Standard Alias Devices*, the path to the signal below the TwinSAFE logic (full name), the link to the PLC (Linked to), and the name in the process image of the TwinSAFE logic are displayed.

Linking **Process Image**

Linking Mode: **Manual**

Full Name: TIID^Device 1 (EtherCAT)^Term 5 (EK1100)^Term 8 (EL6910)^Si

Linked to: TIPC^MainPLC^MainPLC Instance^PlcTask Outputs^MAIN.bErrA

Name: TwinSafeGroup1.ErrAck_1

Fig. 75: Path view for Standard Alias Devices

4.3.7.8 Multiline comments

Comments in the TwinSAFE project may now be multiline.




Fig. 76: Multiline comments

4.3.7.9 Names of Alias Devices in the process image

The user has now the option of adapting the naming of process data below the TwinSAFE logic in the I/O tree. For this purpose, checkboxes are available on the *Target System* dialog to accept the naming of TwinSAFE connections and standard inputs and outputs from the respective *Alias Device* names.



Fig. 77: Properties under Target System

After the checkboxes are set, the names of the alias devices are taken.




Fig. 78: Take Alias Device Name - Safety Project

In the I / O tree below the TwinSAFE logic, the project is shown in the following screenshot. The name consists of the group name, alias device name, and a running index.




Fig. 79: Take Alias Device Name - TwinSAFE logic process image

4.3.7.10 Project settings - Verification

The project settings can be found below the target system.

Safe Address Verification

The Safe Address Verification entry is used to set how the safety addresses are checked.

- Project wide unique (recommended) - Unique safety addresses within the entire solution
- Similar to TwinCAT 2 - Unique addresses per TwinSAFE Logic
- Allow multiple usage - Multiple safety addresses are possible (Validation by the user necessary)

The screenshot shows the 'Project Settings' window. On the left, a sidebar contains 'Target System', 'User Administration', 'Backup/Restore', and 'Project Settings' (highlighted in blue). The main area has 'Configuration: N/A' and 'Platform: N/A' at the top. Below, the 'Verification Settings' section contains two dropdown menus. The first, 'Safe Address Verification', is set to 'Project wide unique (recommended)'. The second, 'FB InPort Activation Verification', is set to 'Project wide unique (recommended)' and has a dropdown menu open showing three options: 'Project wide unique (recommended)', 'Similar to TwinCAT 2', and 'Allow multiple usage'.

Fig. 80: Safe Address Verification

FB InPort Activation Verification

The *FB InPort Activation Verification* entry is used to determine how the input ports of TwinSAFE FBs are checked.

- Strict activated & connected (recommended) - Each enabled port must be connected and each connected port must be enabled.
- Activated or connected allowed - If a port is only activated or only connected, this does not lead to an error message.


This screenshot is similar to Fig. 80, showing the 'Project Settings' window. The 'Safe Address Verification' dropdown remains at 'Project wide unique (recommended)'. The 'FB InPort Activation Verification' dropdown is now set to 'Strict activated & connected (recommended)' and its menu is open, showing three options: 'Strict activated & connected (recommended)', 'Strict activated & connected (recommended)', and 'Activated or connected allowed'.

Fig. 81: FB InPort Activation Verification

4.3.7.11 Displaying the project size

Diagnostic Properties of the project node

If the project node of the TwinSAFE project is selected, the properties under the entry Diagnostic show the current project parameters. These are e.g. the project size in bytes, the number of connections, the number of function blocks, or the number of TwinSAFE groups.




Safety Sample Project Properties	
Diagnostic	
Complete Project Configuration Size (in Byte)	144
Number of FSoE Master Connections	2
Number of FSoE Slave Connections	0
Number of Functionblocks	3
Number of PROFI-safe Master Connections	0
Number of PROFI-safe Slave Connections	0
Number of Safety Alias Devices	2
Number of Standard Alias Devices	2
Number of TwinSAFE Groups	1
Number of TwinSAFE SC Master Connections	0

Fig. 82: Project Properties - Diagnostic

Diagnostic Properties of the group node

If the group node of the TwinSAFE project is selected, the properties under the entry Diagnostic display the current TwinSAFE group parameters. These are e.g. the number of connections, the number of function blocks, or the number of standard signals.



TwinSafeGroup1 Folder Properties	
Diagnostic	
Number of FSoE Master Connections	2
Number of FSoE Slave Connections	0
Number of Functionblocks	3
Number of PROFI-safe Master Connections	0
Number of PROFI-safe Slave Connections	0
Number of Safety Alias Devices	2
Number of Standard Alias Devices	2
Number of TwinSAFE SC Master Connections	0

Fig. 83: Group Properties - Diagnostic

4.3.7.12 Copy and Paste for FBs and comments

The copy and paste function refers to function blocks, comments and connections between function blocks. The copied variable names and links remain unchanged, the FB instances are automatically incremented (here FBStop1 becomes FBStop2).




Fig. 84: Copying the data

After inserting the data, the following message appears. The user may have to adjust copied variable names.




Fig. 85: Message box after inserting the data




Fig. 86: Inserted data

Here, in the example, the user must adapt the links of the output EStopOut and change the variable names Restart, Input_01, Input_02 and EDM so that no duplicate names are assigned.

4.3.7.13 Global settings in Visual Studio

You can select options from the Tools menu in Visual Studio. These options can be used to make settings for the TwinSAFE environment.




Fig. 87: Visual Studio - Menu Tools / Options

Under *TwinCAT / TwinSAFE Environment / Default Info Data* you can configure which info data should be activated automatically when creating TwinSAFE projects, groups, connections or FBs.




Fig. 88: Global setting - Default Info Data

Under *TwinCAT / TwinSAFE Environment / Group Diagram Editor*, you can define whether the undo / redo should be automatically zoomed in and scrolled to the area that has changed.




Fig. 89: Global setting - Group Diagram Editor

4.3.7.14 Sorting

Set the processing order of the groups via dialog

The execution order of the TwinSAFE groups can be accessed via the context menu of the project node.




Fig. 90: Context menu - Edit TwinSAFE Group Order

By selecting a group and then holding and dragging an entry with the mouse, the execution order of the groups can be changed. The new order is accepted with the OK button.




Fig. 91: Execution order of TwinSAFE groups

Sorting of Alias Devices

The display order of the alias devices can be configured via the context menu of the node Alias Devices.




Fig. 92: Sorting of Alias Devices

Sorting of FBs (Execution order)

The execution order of the function blocks can be accessed via the context menu within the graphical worksheet.




Fig. 93: Context menu - Change Execution Order of FBs

By selecting an FB and then holding and dragging an entry with the mouse, the execution order of the function blocks can be changed. The new order is accepted with the OK button




Fig. 94: Execution order FBs

4.3.7.15 Direct mapping of local I/Os

If a TwinSAFE logic has local inputs and outputs, e.g. an EK1960, an assignment to safe and non-safe signals can be made by the user via the *Internal Direct Mapping* tab of the alias device. These direct assignments have the advantage that no logic program has to be created by the user for this purpose.

To use the internal direct mapping, the linking mode of the *Alias Device* must be set to local.




Fig. 95: Internal Direct Mapping

Typical applications are linking the ErrAck signal of the modules to a *Standard Alias Device* or switching an output due to a safe input signal.

In the figure, the relay output *FSOUT relay modules Channel 1.Output* is switched by the safe input *Term (15) (EL1904) - Module 1 (FSOES) InputChannel 1*.

4.3.7.16 Backup/Restore settings

Backup/restore settings have been extended so that TwinSAFE logic components can also be used to store a TwinSAFE project CRC. The following table describes the settings for each TwinSAFE connection listed in the Backup/Restore dialog.

Checkbox	Description	Available in
Store Project CRC in Slave	Only active when FSoE Connection Type is set to Master. The CRC of the local project is stored on the target slave and can be used for the backup/restore mechanism. Now, besides the EL1904 and EL2904, TwinSAFE logics are also supported for storing the CRC.	EL69xx, EL1904, EL2904, EP1908
Store Slave Project CRC in Master	Only active when FSoE Connection Type is set to Master. If the target slave is a logic component that uses the backup/restore mechanism, the project CRC of the logic project of the target slave must be entered manually here.	EL691x, EK1960, EJx9xx and newer products
Store Master Project CRC in Slave	Only active if FSoE Connection Type is set to Slave. The FSoE master sends a CRC to be stored on the local TwinSAFE component so that it can be used for a restore function on the remote FSoE master. This checkbox can be used even if the local backup/restore function is not active.	EL691x, EK1960, EJx9xx and newer products
Read Project CRC from Master	Only active if FSoE Connection Type is set to Slave. The CRC, which is entered on the FSoE master (see Store Slave Project CRC in Master), can be read by the FSoE slave for the local restore function.	EL691x, EK1960, EJx9xx and newer products

Target System
User Administration
Backup/Restore
Project Settings

Configuration: N/A Platform: N/A

☒ Activate Backup/Restore

Available Alias Devices for Backup/Restore-Mode

Alias Device	Store Project CRC in Slave	Store Slave Project CRC in Master	Store Master Project CRC in Slave	Read Project CRC from Master
Term 13 (EL1904) - Module 1 (FSOES) (TwinSafeGroup 1)	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Term 15 (EL2904) - Module 1 (FSOES) (TwinSafeGroup 1)	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Term 16 (EL1904) - Module 1 (FSOES) (TwinSafeGroup 1)	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Term 17 (EL1904) - Module 1 (FSOES) (TwinSafeGroup 1)	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
EL6910 FSoE Connection (TwinSafeGroup 1)	<input checked="" type="checkbox"/>	0x67A6	<input type="checkbox"/>	<input type="checkbox"/>

Restore, if 3 from 5 FSoE-Connections have the correct CRC stored

User Administration

☒ Restore User Administration

Fig. 96: Backup/Restore settings

4.4 Info Data

4.4.1 Info data for the connection

Info data for connections can be enabled on the *Connection* tab of the alias device.

Linking Connection Safety Parameters Process Image

Connection:

Info Data

☒ Map State ☒ Map Inputs

☒ Map Diag ☐ Map Outputs

Fig. 97: Enabling the info data for connections

The info data are shown in the I/O tree structure below the EJ6910 in the process image. From here, these signals can be linked with PLC variables. Further information on the included data can be found in the documentation for *TwinCAT function blocks for TwinSAFE logic terminals*.




Fig. 98: Info data for the connection in the I/O tree structure

4.4.2 Info data for function blocks

Info data for function blocks can be enabled in the properties of the function block.




Fig. 99: Enabling the info data for function blocks

The info data are shown in the I/O tree structure below the EJ6910 in the process image. From here, these signals can be linked with PLC variables. Further information on the included data can be found in the documentation for *TwinCAT function blocks for TwinSAFE logic terminals*.




Fig. 100: Info data for the function block in the I/O tree structure

4.4.3 Info data for the TwinSAFE group

Info data for TwinSAFE groups can be enabled via the properties of the TwinSAFE group.




Fig. 101: Enabling the info data in the properties of the TwinSAFE group

The info data are shown in the I/O tree structure below the EJ6910 in the process image. From here, these signals can be linked with PLC variables. Further information on the included data can be found in the documentation for *TwinCAT function blocks for TwinSAFE logic terminals*.




Fig. 102: Info data for the TwinSAFE group in the tree structure

4.4.4 Info data for the device

The info data for the EJ6910 can be enabled on the *Target System* tab. These are the serial number of the EJ6910 and the current online CRC of the safety project.




Fig. 103: Enabling the info data for the EL6910

The info data are shown in the I/O tree structure below the EJ6910 in the process image. From here, these signals can be linked with PLC variables.





Fig. 104: Info data of the EJ6910 in the tree structure

4.5 Version history

The *version history* button  under *Target System* can be used to read the version history of the EL6910, EJ6910 or EK1960. It includes the user, the date, the version and the CRC of the safety projects loaded on the EL6910, EJ6910 or EK1960.




Fig. 105: Version History

4.6 User Administration

User administration is called up via the *Target System* tree item. Use *Get User List* to read the current list of users from the EL6910, EJ6910 or EK1960. The user *Administrator* cannot be deleted. The default password can and should be replaced with a customer-specific password. This is done via the *Change Password* button. The default password is *TwinSAFE*. The password must be at least 6 characters long. A maximum of 40 users can be created.

The screenshot shows the 'User Administration' window. At the top, there are dropdowns for 'Configuration' (N/A) and 'Platform' (N/A). Below these, the 'Target System' is set to 'EL6910', 'Physical Device' to 'Term 4 (EL6910)', and 'Serial Number' to '00123456'. A 'User List' table contains one user, 'Administrator'. To the right of the table are five buttons: 'Get User List', 'Add User(s)', 'Delete User(s)', 'Change Password', and 'Change Access Rights'.

Fig. 106: User Administration

The administrator password is required to create or delete users. Open the *Login* dialog by left-clicking on *Add User(s)*.

The 'Add New User(s)' dialog box is shown. It has a 'Steps' sidebar on the left with 'Login' selected. The main area is titled 'Login' and contains three input fields: 'Username' (Administrator), 'Serial Number' (empty), and 'Password' (empty). There are red exclamation marks next to the 'Serial Number' and 'Password' fields. At the bottom right are 'Next' and 'Cancel' buttons.


Fig. 107: User Administration - Login

The *Add User* dialog opens once the correct serial number and administrator password have been entered.

Fig. 108: User Administration - Add New User(s)

Fig. 109: User Administration - Add new User(s) - Access Rights

Enter the new user and the corresponding password (twice). The password must be at least 6 characters

long. In addition, select the rights for the new user. Use the  button to apply these data and display them in the New User list.




Fig. 110: User Administration - New User added

Use the *Finish* button to exit the dialog.

Access Rights	Description
Change Password	Users can change their password.
Download Safe Logic Data	The user can load the safety program onto the EL6910, EJ6910 or EK1960.
Download Mapping Data	The user can load the mapping data for inputs, outputs, FBs etc. onto the EL6910, EJ6910 or EK1960.
Download Safe User Data / Replacement Values	The user can change safe user parameters on the EL6910, EJ6910 or EK1960 change and also change and load safe substitute values
Download Info Data	The user can activate and load the info data for connections and FBs on the EL6910, EJ6910 or EK1960.
Download Project Data in Restore Mode	The user is allowed to perform a restore. Currently not supported.
Activate / Deactivate Groups	The user can execute Customizing (enable and disable of TwinSAFE groups) on the EL6910, EJ6910 or EK1960.

4.7 Backup/Restore

Following the exchange of an EL6910, EJ6910 or EK1960, the previous project can be loaded to the new device using the *Backup/Restore* mechanism.

In order to be able to use this functionality, the *Backup/Restore* mechanism must be enabled in the safety project, and the terminals must be selected, on which the current CRC of the safety project is to be stored.

For a restore operation the user can specify the minimum number of selected terminals on which the correct CRC must be stored.

Using the checkbox *Restore User Administration* the user can specify whether the user administration should be transferred to the new device via the restore mechanism.

Target System

User Administration

Backup/Restore

Configuration: N/A Platform: N/A

☒ Activate Backup/Restore

Available Alias Devices for Backup/Restore-Mode

- ☒ Term 5 (EL2904) - Module 1 (FSOES) (TwinSafeGroup1)
- ☒ Term 7 (EL1904) - Module 1 (FSOES) (TwinSafeGroup1)

Restore, if 1 from 2 FSoE-Slaves have the correct CRC stored

User Administration

☒ Restore User Administration

Fig. 111: Backup/Restore

In order to be able to use the *Backup/Restore* mechanism, create a backup of the current safety project and store it on the hard disk of the controller, for sample. To carry out a restore, the user can either check when starting the controller whether the serial number of the EL6910, EJ6910 or EK1960 has changed, or start the restore manually via a service menu, e.g. in the visualization. Detailed information about the *Backup/Restore* mechanism is available from Beckhoff Support.

**Note****Restore**

If a project that doesn't match the system is loaded during a *restore*, this will only be detected when the distributed CRCs are checked. The previous project is then deleted from the logic terminal. This cannot be undone.

One possible sequence for checking whether a restore is carried out is shown in the following flow chart.




Fig. 112: Restore check flow chart

Function blocks for backup/restore

The PLC function blocks with which a backup and restore to a TwinSAFE logic component (currently EL6910, EJ6910 or EK1960) can be carried out are available through Beckhoff Support. This is a compiled library that can be installed in the TwinCAT Library Repository.

The TC3_EL6910_Backup_Restore library contains two PLC function blocks. FB_SAVELOGICPROGRAM and FB_RESTORELOGICPROGRAM.

FB_SAVELOGICPROGRAM




Fig. 113: FB_SAVELOGICPROGRAM illustration

FUNCTION_BLOCK FB_SAVELOGICPROGRAM

Name	Type	Inherited from	Address	Initial	Comment
bExecute	BOOL			FALSE	Positive edge starts the backup process
au8EcatNetId	ARRAY [0..5] OF BYTE				EtherCAT Net-ID of the TwinSAFE Logic - link to e.g. EL6910/InfoData/AdsAddr/netId
u16EcatPort	WORD				Port of TwinSAFE-Logic - link to e.g. EL6910/InfoData/AdsAddr/port
u32BufferAddress	PVOID				Address of buffer, in which the TwinSAFE Logic program should be stored temporarily - buffer e.g. ARRAY[0..16#FFFF] OF BYTE
u32BufferSize	DWORD				size of buffer
sFileName	T_MaxString				File, in which the TwinSAFE Logic program should be stored
sNetIDWriteFile	T_AmsNetID				AmsNetID of device where the file should be written to
Done	BOOL			FALSE	User information that the FB finished the operation
sResult	STRING(200)				FB Result
bErr	BOOL				An error occurred during operation, details in sResult

Fig. 114: FB_SAVELOGICPROGRAM parameters

FB_RESTORELOGICPROGRAM




Fig. 115: FB_RESTORELOGICPROGRAM illustration

FUNCTION_BLOCK FB_RESTORELOGICPROGRAM

Name	Type	Inherited from	Address	Initial	Comment
bExecute	BOOL			FALSE	Positive edge starts the restore process
au8EcatNetId	ARRAY [0..5] OF BYTE				EtherCAT-Net-ID of the TwinSAFE Logic - link to e.g. EL6910/InfoData/AdsAddr/netId
u16EcatPort	WORD				Port of TwinSAFE-Logic - link to e.g. EL6910/InfoData/AdsAddr/port
u32BufferAddress	PVOID				Address to buffer, in which the TwinSAFE Logic program should be stored - buffer e.g. ARRAY[0..16#FFFF] OF BYTE
u32BufferSize	DWORD				size of buffer
sFileName	T_MaxString				File which contains the TwinSAFE logic program and should be restored
sNetIDReadFile	T_AmsNetID				AmsNetID of device where the file is stored
Done	BOOL			FALSE	User information that the FB finished the operation
sResult	STRING(200)				FB result
bErr	BOOL				An error occurred during operation, details in Result

Fig. 116: FB_RESTORELOGICPROGRAM parameters

Sample

```

PROGRAM MAIN
VAR
    fb_save: FB_SAVELOGICPROGRAM;
    fb_restore: FB_RESTORELOGICPROGRAM;
    StartBackup: BOOL;
    EL6910AmsNetID AT %I*: ARRAY [0..5] OF BYTE;
    EL6910port AT %I*: WORD;
    internalBuffer: array[0..16#FFFF] of byte;
    FileString: T_MaxString := 'c:\temp\safety\complibTest_EL6910.bin';
    LocalAmsNetID: T_AmsNetID := '172.55.76.53.1.1';
    SaveDone: BOOL;
    SaveResult: STRING(200);
    SaveErr: BOOL;
    StartRestore: BOOL;
    internalbuffer2: array[0..16#FFFF] of Byte;
    RestoreDone: BOOL;
    RestoreResult: STRING(200);
    RestoreErr: BOOL;

```

```

END_VAR

// Backup of the TwinSAFE logic program
fb_save(
    bExecute:=          StartBackup,
    au8EcatNetId:=       EL6910AmsNetID,
    u16EcatPort:=        EL6910port,
    u32BufferAddress:=   ADR(internalBuffer),
    u32BufferSize:=      SIZEOF(internalBuffer),
    sFileName:=          FString,
    sNetIDWriteFile:=    LocalAmsNetID,
    Done=>               SaveDone,
    sResult=>            SaveResult,
    bErr=>               SaveErr);

// Restore of the TwinSAFE logic program
fb_restore(
    bExecute:=          StartRestore,
    au8EcatNetId:=       EL6910AmsNetID,
    u16EcatPort:=        EL6910port,
    u32BufferAddress:=   ADR(internalbuffer2),
    u32BufferSize:=      SIZEOF(internalBuffer2),
    sFileName:=          FString,
    sNetIDReadFile:=     LocalAmsNetID,
    Done=>               RestoreDone,
    sResult=>            RestoreResult,
    bErr=>               RestoreErr);

```

4.8 Export/import of the safety project

The safety project can be archived via the context menu of the safety project. The data type of this archive is *.tfzip.




Fig. 117: Archiving the safety project

The safety project can be exported to XML format one level below the safety project node. This XML format can be used for exchange between TwinCAT 3 and TwinCAT 2.

The menu item *Export project (as bin file)* can be used to save the safety project in a binary format, so that it can be used by the TwinSAFE loader, for sample.




Fig. 118: Saving the safety project in a binary format (e.g. for the TwinSAFE loader)

A previously exported safety project can be imported via the context menu of the main Safety entry in the TwinCAT project structure. *Add Existing Item...* can be used to select the file type for the import.




Fig. 119: Selecting the file type for importing a safety project

The following file types are supported:

- Safety project files *.splc,
- Safety project archives *.tfzip
- Safety projects in XML format




Fig. 120: Importing a safety project

4.9 Tab Diag history

Any errors that occur in the EL6910, EJ6910 or EK1960 are stored in the their diag history. The diag history can be viewed by selecting the EL6910, EJ6910 or EK1960 in the I/O tree structure and then selecting the *Diag History* tab. Use the *Update History* button to fetch the current from the EL6910, EJ6910 or EK1960. Error within the logic; the function blocks and the connections are stored with a corresponding timestamp.




Fig. 121: Diag History

Use the *Advanced...* button to open the advanced settings. Here, the user can customize the behavior of the diag history.




Fig. 122: Diag History - Advanced Settings

Advanced Settings

Setting	Description
Message Types	<ul style="list-style-type: none"> • disable Info Messages with status <i>Info</i> are not stored in the diag history • disable Warnings Messages with status <i>Warning</i> are not stored in the diag history • disable Errors Messages with status <i>Error</i> are not stored in the diag history
Emergency	In addition to saving the message in the diag history, an emergency object is sent, which is displayed in the logger window of TwinCAT.
Overwrite / Acknowledge Mode	This setting is currently not supported.

4.10 TwinSAFE SC configuration

The TwinSAFE SC technology enables communication with standard EtherCAT terminals via the Safety over EtherCAT protocol. These connections use another checksum, in order to be able to distinguish between TwinSAFE SC and TwinSAFE. Eight fixed CRCs can be selected, or a free CRC can be entered by the user.

By default the TwinSAFE SC communication channel of the respective TwinSAFE SC component is not enabled. In order to be able to use the data transfer, the corresponding TwinSAFE SC module must first be added under the Slots tab. Only then is it possible to link to a corresponding alias device.




Fig. 123: Adding the TwinSAFE SC process data under the component, e.g. EL5021-0090

Additional process data with the ID TSC Inputs, TSC Outputs are generated (TSC - TwinSAFE Single Channel).




Fig. 124: TwinSAFE SC component process data, example EL5021-0090

A TwinSAFE SC connection is added by adding an alias devices in the safety project and selecting TSC (*TwinSAFE Single Channel*)





Fig. 125: Adding a TwinSAFE SC connection

After opening the alias device by double-clicking, select the Link button  next to *Physical Device*, in order to create the link to a TwinSAFE SC terminal. Only suitable TwinSAFE SC terminals are offered in the selection dialog.




Fig. 126: Creating a link to TwinSAFE SC terminal

The CRC to be used can be selected or a free CRC can be entered under the Connection tab of the alias device.

Entry Mode	Used CRCs
TwinSAFE SC CRC 1 master	0x17B0F
TwinSAFE SC CRC 2 master	0x1571F
TwinSAFE SC CRC 3 master	0x11F95
TwinSAFE SC CRC 4 master	0x153F1
TwinSAFE SC CRC 5 master	0x1F1D5
TwinSAFE SC CRC 6 master	0x1663B
TwinSAFE SC CRC 7 master	0x1B8CD
TwinSAFE SC CRC 8 master	0x1E1BD




Fig. 127: Selecting a free CRC

These settings must match the settings in the CoE objects of the TwinSAFE SC component. The TwinSAFE SC component initially makes all available process data available. The *Safety Parameters* tab typically contains no parameters. The process data size and the process data themselves can be selected under the *Process Image* tab.




Fig. 128: Selecting the process data size and the process data

The process data (defined in the ESI file) can be adjusted to user requirements by selecting the *Edit* button in the dialog *Configure I/O element(s)*.




Fig. 129: Selection of the process data

The safety address together with the CRC must be entered on the TwinSAFE SC slave side. This is done via the CoE objects under *TSC settings* of the corresponding TwinSAFE SC component (here, for example, EL5021-0090, 0x8010: 01 and 0x8010: 02). The address set here must also be set in the *alias device* as *FSoE* address under the *Linking* tab.

Under the object 0x80n0:02 Connection Mode the CRC to be used is selected or a free CRC is entered. A total of 8 CRCs are available. A free CRC must start with 0x00ff in the high word.

8010:0	TSC Settings	RW	> 2 <
8010:01	Address	RW	0x0000 (0)
8010:02	Connection Mode	RW	TwinSAFE SC CRC1 master (97039)

Fig. 130: CoE objects 0x8010:01 and 0x8010:02

**Note****Object „TSC Settings“**

Depending on the terminal, the index designation of the configuration object „TSC Settings“ can vary.

Example:

- EL3214-0090 and EL3314-0090, „TSC Settings“, Index 8040
- EL5021-0090, „TSC Settings“, Index 8010
- EL6224-0090, „TSC Settings“, Index 800F

The 'Set Value Dialog' window contains the following fields and controls:


- Dec:** Text box containing '97039'. To its right is an 'OK' button.
- Hex:** Text box containing '0x00017B0F'. To its right is a 'Cancel' button.
- Enum:** A dropdown menu showing 'TwinSAFE SC CRC1 master'.
- Bool:** Two radio buttons labeled '0' and '1'. To their right is a 'Hex Edit...' button.
- Binary:** Text box containing '0F 7B 01 00'. To its right is a small box containing the number '4'.
- Bit Size:** A row of radio buttons with labels '1', '8', '16', '32', '64', and '?'. The '32' option is selected.

Fig. 131: Entering the safety address and the CRC

**Note****TwinSAFE SC connections**

If several TwinSAFE SC connections are used within a configuration, a different CRC must be selected for each TwinSAFE SC connection.

4.11 Customizing / disabling TwinSAFE groups

The function Customizing  can be selected in the safety toolbars or via the TwinSAFE menu. It can be used to enable and disable groups. There are different deactivation methods, as shown in the following table.

Deactivation	Description
Permanent deactivation	<p>The TwinSAFE group is permanently disabled by the user. The substitute values parameterized for the group are set for the group outputs.</p> <p>If this group is enabled again, the RUN signal for this group must change from 0 to 1, in order for the group to start.</p> <p>Parameter: <i>Permanent Deactivation Allowed</i>: TRUE / FALSE</p>
Deactivation until the EL6910 is switched off and back on again	<p>The TwinSAFE group is disabled until the EL6910 is switched on again. The substitute values parameterized for the group are set for the group outputs. This setting cannot be used as default setting for the safety program download.</p> <p>If this group is enabled again (other than by switching off and on again), the RUN signal for this group must change from 0 to 1, in order for the group to start.</p> <p>Parameter: <i>Temporary Deactivation Allowed</i>: TRUE / FALSE</p>
Deactivation of manual control unit	<p>After starting the deactivation, the connection defined in the group must report a COM error after a period of 10 seconds, for sample (default setting). If this is not the case, a group error set and corresponding diagnostic message is generated. Only one connection may be defined in the group, which must be a master connection.</p> <p>Parameter: <i>Passification Allowed</i>: TRUE / FALSE <i>Timeout Passification Allowed</i>: Time in ms</p>

The customization can also be carried out during the download of the safety application.

In order to be able to perform a customization, the groups must be set accordingly. This is done via the group properties.




Fig. 132: Properties of the TwinSAFE group

If one of the customization parameters (*Passification Allowed*, *Permanent Deactivation Allowed* or *Temporary Deactivation Allowed*) is set to TRUE, all outputs of the TwinSAFE group, which are not SafetyAlias Devices, are listed in the list of *Replacement Values*. Here you can parameterize the substitute values to be written to the output in the event of deactivation of the group.





Fig. 133: Replacement values for the TwinSAFE group

When the Customizing function  is selected, the login dialog opens for the user to enter their login data. This login must give permission for customizing.




Fig. 134: Login

The Customizing dialog opens once the user has entered the data and selected *Next*.

The current group status is indicated with a green background.



Fig. 135: Customizing TwinSAFE Groups

The user can select the new status via the option area. In the sample below *Deactivate Temporarily* is selected. Use the *Finish* button to close the dialog and execute the required option.



Fig. 136: Customized TwinSAFE Group

4.12 Saving the analog group inputs persistently

EL6910, EJ6910 and EK1960 support persistent saving of analog input values in an internal memory. When the group starts up, the stored data are compared with the current data. Under the tab *Max Start Deviation*, a corresponding deviation can be specified for each defined analog input value of the group.







Fig. 137: Specifying deviations for analog input values

In the group properties the general settings for setting substitute values and checking the analog values on group startup can be parameterized. Setting the parameter *Verify Analog FB Inputs at Group Startup* to TRUE activates saving of all analog group inputs.

Properties

TwinSAFE Safety Application

☐ **Customization Settings**

Passification Allowed	False
Permanent Deactivation Allowed	False
Temporary Deactivation Allowed	False
Timeout Passification Allowed (ms)	10000

☐ **Failsafe Settings**

Analog FB Output Failsafe Values	Zero
----------------------------------	------

☐ **Info Data**

Map Diag	False
Map State	False

☐ **Parameter Settings**

Group Order Id	0
----------------	---

☐ **Startup Settings**

Verify Analog FB Inputs at Group Startup	False
--	-------

Fig. 138: Activate saving of all analog group inputs

4.13 Project design limits of EL6910/EJ6910



Note

Project design limits

The maximum project design size for EL6910/EJ6910 is determined by the available memory. This is managed dynamically. The values specified in the following table are therefore only guide values and may differ from the actual values, depending on the safety project.

Process image size	max. 1486 byte per data direction (maximum memory size 0x1E00 for 3 buffers, ie with the same size of input and output process data, a maximum size of 1280 bytes per data direction is possible. Only straight start addresses are possible, so fill bytes must be taken into account)
TwinSAFE connections	212 max. (up to 255 CRCs in total; 1 CRC is required for a TwinSAFE connection with 1 or 2 byte safe data.)
Supported hardware for EL6910/EJ6910 TwinSAFE connections	EL1904 (all) EL2904 (all) EL2902 (all) EL6900 (all - max. 14 byte safe data) EL6930 (all - max. 14 byte safe data) EL6910 (all - max. 126 byte safe data) EJ6910 (all - max. 126 byte safe data) KL1904 (from 2008) KL2904 (from 2008) KL6904 as slave (from 2008) AX5805 (all) AX5806 (all)
Safe data per TwinSAFE connection	maximum 126 byte (telegram length 255 byte)
PROFIsafe telegram length	4 to 16 byte PROFIsafe telegram length (user data 0 - 12 byte)
TwinSAFE blocks	maximum 512 (ESTOP with complete input and output mapping)
TwinSAFE groups	128 max.
TwinSAFE user	40 max.
Standard PLC inputs	dynamic (memory-dependent), max. 1024 byte
Standard PLC outputs	dynamic (memory-dependent), max. 1024 byte



Note

TwinSAFE connection

Only one TwinSAFE connection between two TwinSAFE terminals is possible. For communication with a EL6900, for sample, a connection with up to 14 bytes safe user data can be used.

4.14 Sync-Manager Configuration

Depending on the size of the TwinSAFE project on the TwinSAFE logic, it may be necessary to adjust the sync manager configuration.

As soon as the following message appears during the saving or downloading of the project, the sync manager configuration for the device has to be adapted.




Fig. 139: Overlapping Sync Manager

Adapting the Sync-Manager configuration

The Sync Manager settings can be made via the *Advanced Settings...* of the TwinSAFE logic.




Fig. 140: EtherCAT Advanced Settings

To calculate the smallest start address of SM3, the length of SM2 is multiplied by 3 and added to the start address of SM2.

$$\text{Start SM3} \geq \text{Start SM2} + 3 * \text{Length SM2}$$

In addition, the starting address, together with 3 times the length of SM3, must not be larger than the address 0x3000.

$$\text{Start SM3} + 3 * \text{Length SM3} \leq 0x3000$$




Fig. 141: Sync Manager settings




Fig. 142: Setting the start address for SM3

After changing the start address, all dialogs are closed with OK, the TwinCAT project is saved and the configuration is activated. If the calculation was carried out correctly, no error message should now be displayed and the project should be executed without errors.

4.15 TwinSAFE reaction times

The TwinSAFE terminals form a modular safety system that exchanges safety-oriented data via the Safety-over-EtherCAT protocol. This chapter is intended to help you determine the system's reaction time from the change of signal at the sensor to the reaction at the actuator.

Typical reaction time

The typical reaction time is the time that is required to transmit information from the sensor to the actuator, if the overall system is working without error in normal operation.




Fig. 143: Typical reaction time

Definition	Description
RTSensor	Reaction time of the sensor until the signal is provided at the interface. Typically supplied by the sensor manufacturer.
RTInput	Reaction time of the safe input, such as EL1904 or EP1908. This time can be found in the technical data. In the case of the EL1904 it is 4 ms.
RTComm	Reaction time of the communication. This is typically 3x the EtherCAT cycle time, because new data can only be sent in a new Safety-over-EtherCAT telegram. These times depend directly on the higher-level standard controller (cycle time of the PLC/NC).
RTLogic	Reaction time of the logic terminal. This is the cycle time of the logic terminal and typically ranges from 500 µs to 10 ms for the EL6900, depending on the size of the safety project. The actual cycle time can be read from the terminal.
RTOutput	Reaction time of the output terminal. This typically lies within the range of 2 to 3 ms.
RTActor	Reaction time of the actuator. This information is typically supplied by the actuator manufacturer.
WDComm	Watchdog time of the communication

This results in the following equation for the typical reaction time:

$$ReactionTime_{typ} = RT_{Sensor} + RT_{Input} + 3 * RT_{Comm} + RT_{Logic} + 3 * RT_{Comm} + RT_{Output} + RT_{Actor}$$

with, for example

$$ReactionTime_{typ} = 5ms + 4ms + 3 * 1ms + 10ms + 3 * 1ms + 3ms + 20ms = 48ms$$

Worst-case reaction time

The worst case reaction time is the maximum time required to switch off the actuator in the case of an error.




Fig. 144: Worst-case reaction time

This assumes that a signal change occurs at the sensor and is transmitted to the input. A communication error occurs at precisely the moment when the signal is to be transferred to the communication interface. This is detected by the logic following the watchdog time of the communication link. This information should then be transferred to the output, but a further communication error occurs here. This error is detected at the output following the expiry of the watchdog time and leads to the switch-off.

This results in the following equation for the worst-case reaction:

$$ReactionTime_{max} = WD_{Comm} + WD_{Comm} + RT_{Actor}$$

with, for example

$$ReactionTime_{max} = 2 * 15ms + 20ms = 50ms$$

4.16 Diagnostics

4.16.1 Diagnostic LEDs

The LEDs Diag 1 to Diag 4 display diagnostic information for the EJ6910.




Fig. 145: EJ6910 diagnostic LEDs

4.16.1.1 LED indicators

Diagnostic LEDs

LED	lit	flashing	off
Diag 1 (green)	Environment variables, operating voltage and internal tests are in the valid range <ul style="list-style-type: none"> If Diag 2 flashes, a logic error code applies 	-	Environment variables, operating voltage and internal tests are outside the valid range <ul style="list-style-type: none"> If Diag 2 flashes, an environment error code applies
Diag 2 (red)	Together with Diag 3 and 4: Global shutdown ¹⁾ has occurred. (see diag history of the TwinSAFE components)	Logic or environment error code according to Diag1 and tables below is output	Together with Diag 3 and 4: Global fault ¹⁾ has occurred. (see diag history of the TwinSAFE components)
Diag 3 (red)	Global fault or global shutdown on $\mu C1^{1)}$	-	No global fault or global shutdown on $\mu C1^{1)}$
Diag 4 (red)	Global fault or global shutdown on $\mu C2^{1)}$	-	No global fault or global shutdown on $\mu C2^{1)}$

1. A global fault permanently disables the TwinSAFE component, so that it has to be replaced. A global shutdown temporarily disables the TwinSAFE component. The error can be reset by switching off and back on again.



Logic error codes of LED Diag 2 (if LED Diag 1 is lit)

Flashing Code	Description
1	Function block error in one of the TwinSAFE groups
2	Communication error in one of the TwinSAFE groups
3	Error combination: Function block and communication
4	General error in one of the TwinSAFE groups
5	Error combination: General and function block
6	Error combination: General and communication
7	Error combination: General, function block and communication

Environment error codes of LED Diag 2 (if LED Diag 1 is off)

Flashing Code	Description
1	Maximum supply voltage μ C1 exceeded
2	Supply voltage μ C1 below minimum value
3	Maximum supply voltage μ C2 exceeded
4	Supply voltage μ C2 below minimum value
5	Maximum internal temperature exceeded
6	Internal temperature below minimum value
7	Valid temperature difference between μ C1 and μ C2 exceeded
8	not used
9	not used
10	General error

4.16.1.2 Flash code display

LED	Display	Description
flashing		400 ms ON / 400 ms OFF 1 second pause between the flash codes
flickering		50 ms ON / 50 ms OFF

4.16.2 Status LEDs

The LEDs State 1 to State 4 indicate the current status of the EJ6910.



Fig. 146: EJ6910 status LEDs

LED Display

State 1	State 2	State 3	State 4	Meaning
Off	Off	Off	lit	No TwinSAFE project available on the component
Off	Off	lit	lit	TwinSAFE project loaded, but not yet in RUN state
lit	Off	lit	lit	TwinSAFE project loaded and in RUN state. Customization is active for at least one TwinSAFE group
lit	lit	lit	lit	TwinSAFE project loaded and in RUN state. Customization is NOT active

4.16.3 Diagnostic objects



CAUTION

Do not change CoE objects!

Do not make any modifications to the CoE objects in the TwinSAFE components! Any modifications (e.g. using TwinCAT) of the CoE objects will permanently set the TwinSAFE components to the Fail-Stop state.

Index F984_{hex}: Device Info Data C1

CoE object F984_{hex} currently displays internal temperature and voltage values for the TwinSAFE component.

Index	Name	Meaning	Flags	Default
F984:01	Voltage C2	Voltage μ C2	RO	0 _{dec}
F984:02	Temperature C1	Temperature μ C1	RO	0 _{dec}

Index F985_{hex}: Device Info Data C2

CoE object F985_{hex} currently displays internal temperature and voltage values for the TwinSAFE component.

Index	Name	Meaning	Flags	Default
F985:01	Voltage C1	Voltage μ C1	RO	0 _{dec}
F985:02	Temperature C2	Temperature μ C2	RO	0 _{dec}

**Note****Diagnostics history**

Any errors, which occur during operation of the TwinSAFE component, such as overtemperature or undervoltage, are entered in the diagnostics history with a corresponding time-stamp.

Index F100_{hex}: FSLOGIC status

The CoE object F100_{hex} shows the current status of the TwinSAFE component.

Index	Name	Meaning	Flags	Default
F100:01	Safe Logic State	Status of the internal logic: 0: OFFLINE 1: RUN 2: STOP 3: SAFE 4: ERROR 6: START 8: PREPARE 10: RESTORE 11: PROJECT-CRC-OK	RO	0 _{bin}
F100:02	Cycle Counter	Life cycle counter, which is incremented with each TwinSAFE logic cycle.	RO	0 _{bin}

This CoE object is additionally copied into the cyclic process image of the TwinSAFE component. From there, this information can be directly linked into the PLC.




Fig. 147: Diagnostic object: FSLOGIC Status (F100_{hex}) in the process image of the TwinSAFE component.

4.16.4 Cycle time of the safety project

The processing time of the EL6910/EJ6910 can be obtained from the CoE objects below. To determine the cycle time, it has to be multiplied with 1.25, because this is the factor used internally for generating a delay time before the next cycle.

4.16.4.1 Index FEA0hex: CTRL Diag Data

Index	Name	Meaning	Flags	Default
FEA0:09	Actual Safety Control Task Execution Time	Current processing time of the EL6910/EJ6910 when logic state = 1 (RUN) cycle time = 1.25 * value (average value of 64 cycles)	RO	0 _{hex}
FEA0:0A	Min Safety Control Task Execution Time	Minimum processing time of the EL6910/EJ6910 when logic state = 1 (RUN) cycle time = 1.25 * value	RO	0 _{hex}
FEA0:0B	Actual Safety Control Task Execution Time	Maximum processing time of the EL6910/EJ6910 when logic state = 1 (RUN) cycle time = 1.25 * value	RO	0 _{hex}
FEA0:15	Actual Safety Control Task Execution Time	Current processing time of the EL6910/EJ6910 when logic state <> 1 cycle time = 1.25 * value (average value of 64 cycles)	RO	0 _{hex}
FEA0:16	Min Safety Control Task Execution Time	Minimum processing time of the EL6910/EJ6910 when logic state <> 1 cycle time = 1.25 * value	RO	0 _{hex}
FEA0:17	Actual Safety Control Task Execution Time	Maximum processing time of the EL6910/EJ6910 when logic state <> 1 cycle time = 1.25 * value	RO	0 _{hex}


The minimum and maximum values can be reset by writing a value to CoE object 0x1C32:08.

4.17 Maintenance

Maintenance

The TwinSAFE components are maintenance-free!

Environmental conditions


 WARNING	Observe the specified environmental conditions! Please ensure that the TwinSAFE components are only stored and operated under the specified conditions (see technical data).
---	--

If the TwinSAFE component is operated outside the permitted temperature range it will switch to *Global Shutdown* state.

Cleaning

Protect the TwinSAFE component from unacceptable soiling during operation and storage!

If the TwinSAFE component was subjected to unacceptable soiling it may no longer be operated!

 WARNING	Have soiled terminals checked! Cleaning of the TwinSAFE component by the user is not permitted! Please send soiled terminals to the manufacturer for inspection and cleaning!
---	--

4.18 Service life

The TwinSAFE EJ modules are designed for a service life of 20 years.

Due to the high diagnostic coverage within the lifecycle no special proof tests are required.

The TwinSAFE EJ modules bear a date code, which is composed as follows:

Date code: CW YY SW HW

Legend:

CW: Calendar week of manufacture

YY: Year of manufacture

SW: Software version

HW: Hardware version

Sample: Date Code 17 11 05 00

Calendar week: 17

Year: 2011

Software version: 05


Hardware version: 00

In addition the TwinSAFE EJ modules bear a unique serial number.



Fig. 148: Unique serial number of a TwinSAFE EJ module

4.19 Decommissioning

 DANGER	<p>Serious risk of injury!</p> <p>Bring the bus system into a safe, de-energized state before starting disassembly of the devices!</p>
--	---

Disposal

In order to dispose of the device, it must be removed and fully dismantled.

- Housing components (polycarbonate, polyamide (PA6.6)) are suitable for plastic recycling.
- Metal parts can be sent for metal recycling.
- Electronic parts such as disk drives and circuit boards must be disposed of in accordance with national electronics scrap regulations.

5 Appendix

5.1 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

Beckhoff's branch offices and representatives

Please contact your Beckhoff branch office or representative for local support and service on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on her internet pages:

<http://www.beckhoff.com>

You will also find further documentation for Beckhoff components there.

Beckhoff Headquarters

Beckhoff Automation GmbH & Co. KG

Huelshorstweg 20
33415 Verl
Germany

Phone:	+49(0)5246/963-0
Fax:	+49(0)5246/963-198
e-mail:	info@beckhoff.com

Beckhoff Support

Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

Hotline:	+49(0)5246/963-157
Fax:	+49(0)5246/963-9157
e-mail:	support@beckhoff.com

Beckhoff Service

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline:	+49(0)5246/963-460
Fax:	+49(0)5246/963-479
e-mail:	service@beckhoff.com

5.2 Certificates

ZERTIFIKAT ♦ CERTIFICATE ♦ 認証証書 ♦ СЕРТИФИКАТ ♦ CERTIFICADO ♦ CERTIFICAT

A1 / 04.11



Product Service

CERTIFICATE

No. Z10 16 11 62386 034

Holder of Certificate: Beckhoff Automation GmbH & Co. KG

Hülshorstweg 20
33415 Verl
GERMANY

Factory(ies): 62386

Certification Mark:



Product: Safety components

Model(s): EJ6910, EL6910

Parameters:

Supply voltage:	24VDC (-15%/+20%)
Temperature range	-5°C ... +55°C
Protection Class:	IP20

Tested according to:

EN 61508-1:2010 (SIL1-3)
EN 61508-2:2010 (SIL1-3)
EN 61508-3:2010 (SIL1-3)
EN 61508-4:2010 (SIL1-3)
EN ISO 13849-1:2015 (up to Cat 4, PL e)
EN 61326-3-1:2008
EN 62061:2005/A2:2015

The product was tested on a voluntary basis and complies with the essential requirements. The certification mark shown above can be affixed on the product. It is not permitted to alter the certification mark in any way. In addition the certification holder must not transfer the certificate to third parties. See also notes overleaf.

Test report no.: BV88453T

Valid until: 2021-12-14

Date, 2016-12-15

(Christian Dirmeier)

Page 1 of 1



TÜV SÜD Product Service GmbH · Zertifizierstelle · Ridlerstraße 65 · 80339 München · Germany

TÜV®

Table of figures

Fig. 1	EtherCAT plug-in module system (EJ)	10
Fig. 2	EJ6910 - TwinSAFE logic module	11
Fig. 3	EJ6910 - dimensions	14
Fig. 4	Installation position and minimum distances	16
Fig. 5	TwinCAT - adding an EJ6910	18
Fig. 6	Address setting on TwinSAFE EJ modules with 1023 possible addresses	19
Fig. 7	Creating a safety project - Add New Item	20
Fig. 8	Creating a safety project - project name and directory	20
Fig. 9	TwinCAT Safety Project Wizard	21
Fig. 10	Selecting the Target System node	21
Fig. 11	Starting the automatic import from the I/O configuration	22
Fig. 12	Selection from the I/O tree	23
Fig. 13	Creating alias devices by the user	23
Fig. 14	Alias device in the safety project structure	24
Fig. 15	Links to the EL6910/EJ6910 process image	24
Fig. 16	Connection-specific parameters	24
Fig. 17	Selecting an alias device	25
Fig. 18	Safety parameters of the device	26
Fig. 19	AX5000 safety drive functions	26
Fig. 20	AX5000 safety drive options - general AX5805 settings	27
Fig. 21	AX5000 safety drive options - Process Image	27
Fig. 22	AX5000 safety drive options - Function Diagram	28
Fig. 23	Creating an external connection (Custom FSoE Connection)	29
Fig. 24	Parameterization of the process image size	29
Fig. 25	Renaming the individual signals within the telegram	30
Fig. 26	Selecting the variable	30
Fig. 27	Direct linking with the process image of an EtherCAT Terminal	31
Fig. 28	Connection-specific parameters	31
Fig. 29	Function blocks available for EL6910/EJ6910	33
Fig. 30	Function block on the sal worksheet	33
Fig. 31	Dragging a connection between two function blocks	34
Fig. 32	Connection between two function blocks	35
Fig. 33	Creating a network	35
Fig. 34	Change Link	36
Fig. 35	Dialog for selecting a suitable FB port	36
Fig. 36	Link display	36
Fig. 37	Creating a TwinSAFE group	37
Fig. 38	Components of the TwinSAFE group	37
Fig. 39	Change Link	38
Fig. 40	Dialog for selecting a suitable FB port	38
Fig. 41	Link display	39
Fig. 42	The Variable Mapping dialog	39
Fig. 43	Context menu Edit TwinSAFE Group Order	41
Fig. 44	Dialog Change Execution Order of TwinSAFE Groups	41

Fig. 45	The command line below the SAL worksheet.....	42
Fig. 46	FB port properties	42
Fig. 47	Make Contact (NO) / Break Contact (NC) setting	43
Fig. 48	Menu Change Inport Settings	44
Fig. 49	Dialog Change InPort Settings	44
Fig. 50	Variable Mapping	44
Fig. 51	Selection dialog for the alias port.....	45
Fig. 52	Activation of the TwinCAT Safety and TwinCAT Safety CRC toolbars.....	45
Fig. 53	Display of the TwinCAT Safety and TwinCAT Safety CRC toolbars	45
Fig. 54	Check Safe Addresses context menu.....	47
Fig. 55	Check Safe Addresses dialog.....	47
Fig. 56	Download Project Data – The Login dialog	48
Fig. 57	Download Project Data – The Select Project Data dialog	48
Fig. 58	Download Project Data – The Download Result dialog	49
Fig. 59	Download Project Data – The Final Verification dialog.....	49
Fig. 60	Download Project Data – The Activation dialog.....	50
Fig. 61	SAL worksheet and variable mapping in online mode.....	51
Fig. 62	Activation of Show Online Values	52
Fig. 63	Display of the analog and digital values in online mode	53
Fig. 64	The Safety Project Online View tab	54
Fig. 65	Group Status Online RUN	55
Fig. 66	Group Status Online ERROR	56
Fig. 67	Group Status Online STOP	56
Fig. 68	Online View Group Ports	57
Fig. 69	Templates for Safety Projects.....	57
Fig. 70	Collapsing of networks.....	58
Fig. 71	Adding a subfolder	58
Fig. 72	Subfolder e.g. Drives	58
Fig. 73	Goto Linked Element	59
Fig. 74	Path view for safety Alias Devices.....	59
Fig. 75	Path view for Standard Alias Devices.....	60
Fig. 76	Multiline comments	60
Fig. 77	Properties under Target System.....	61
Fig. 78	Take Alias Device Name - Safety Project.....	61
Fig. 79	Take Alias Device Name - TwinSAFE logic process image	61
Fig. 80	Safe Address Verification	62
Fig. 81	FB InPort Activation Verification	62
Fig. 82	Project Properties - Diagnostic	63
Fig. 83	Group Properties - Diagnostic	63
Fig. 84	Copying the data.....	64
Fig. 85	Message box after inserting the data.....	64
Fig. 86	Inserted data	65
Fig. 87	Visual Studio - Menu Tools / Options	65
Fig. 88	Global setting - Default Info Data.....	66
Fig. 89	Global setting - Group Diagram Editor.....	66
Fig. 90	Context menu - Edit TwinSAFE Group Order.....	67

Fig. 91	Execution order of TwinSAFE groups.....	67
Fig. 92	Sorting of Alias Devices.....	68
Fig. 93	Context menu - Change Execution Order of FBs	68
Fig. 94	Execution order FBs	69
Fig. 95	Internal Direct Mapping.....	69
Fig. 96	Backup/Restore settings.....	71
Fig. 97	Enabling the info data for connections.....	71
Fig. 98	Info data for the connection in the I/O tree structure	72
Fig. 99	Enabling the info data for function blocks	72
Fig. 100	Info data for the function block in the I/O tree structure	73
Fig. 101	Enabling the info data in the properties of the TwinSAFE group	73
Fig. 102	Info data for the TwinSAFE group in the tree structure	74
Fig. 103	Enabling the info data for the EL6910	74
Fig. 104	Info data of the EJ6910 in the tree structure.....	75
Fig. 105	Version History	75
Fig. 106	User Administration	76
Fig. 107	User Administration - Login	76
Fig. 108	User Administration - Add New User(s).....	77
Fig. 109	User Administration - Add new User(s) - Access Rights	77
Fig. 110	User Administration - New User added	78
Fig. 111	Backup/Restore	79
Fig. 112	Restore check flow chart	80
Fig. 113	FB_SAVELOGICPROGRAM illustration.....	81
Fig. 114	FB_SAVELOGICPROGRAM parameters.....	81
Fig. 115	FB_RESTORELOGICPROGRAM illustration.....	81
Fig. 116	FB_RESTORELOGICPROGRAM parameters.....	81
Fig. 117	Archiving the safety project.....	82
Fig. 118	Saving the safety project in a binary format (e.g. for the TwinSAFE loader)	83
Fig. 119	Selecting the file type for importing a safety project	83
Fig. 120	Importing a safety project	84
Fig. 121	Diag History	84
Fig. 122	Diag History - Advanced Settings	85
Fig. 123	Adding the TwinSAFE SC process data under the component, e.g. EL5021-0090	86
Fig. 124	TwinSAFE SC component process data, example EL5021-0090	86
Fig. 125	Adding a TwinSAFE SC connection	86
Fig. 126	Creating a link to TwinSAFE SC terminal	87
Fig. 127	Selecting a free CRC	87
Fig. 128	Selecting the process data size and the process data	88
Fig. 129	Selection of the process data	88
Fig. 130	CoE objects 0x8010:01 and 0x8010:02.....	88
Fig. 131	Entering the safety address and the CRC	89
Fig. 132	Properties of the TwinSAFE group	90
Fig. 133	Replacement values for the TwinSAFE group.....	91
Fig. 134	Login	91
Fig. 135	Customizing TwinSAFE Groups	91
Fig. 136	Customized TwinSAFE Group.....	92

Fig. 137 Specifying deviations for analog input values.....	92
Fig. 138 Activate saving of all analog group inputs	93
Fig. 139 Overlapping Sync Manager	95
Fig. 140 EtherCAT Advanced Settings.....	95
Fig. 141 Sync Manager settings	96
Fig. 142 Setting the start address for SM3	96
Fig. 143 Typical reaction time	97
Fig. 144 Worst-case reaction time	98
Fig. 145 EJ6910 diagnostic LEDs.....	99
Fig. 146 EJ6910 status LEDs	101
Fig. 147 Diagnostic object: FSLOGIC Status (F100hex) in the process image of the TwinSAFE component.....	102
Fig. 148 Unique serial number of a TwinSAFE EJ module.....	104