

Software to help users choose the correct power supply, check voltage drop is not too large, and verify the configuration of an AS-Interface network
Intel® Pentium® III processor or better 20 GB of available hard disk memory 521 MB RAM CD-ROM or DVD drive Serial interface on PC
Microsoft Windows Win 98 SE, Win Me, Win 2000, Win XP, NT4, Vista 32 Bit

Technical data

Model number

AS-Interface Power Calculator

AS-Interface Power supply and network checking utility

Features

- Straightforward operation ٠
- Checks to make sure AS-i network • configuration is Okay
- Calculates Voltage drop of AS-i cable ٠
- Calculates AS-i and Auxiliary power • supply load

Pepperl+Fuchs Group

www.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



1

AS-Interface Power Calculator