


Installationsanleitung uniVision Decode/Patternmatch Offline-Lizenz

1. Stecken Sie den USB-Dongel in einen freien USB-Port.



2. Legen Sie die Lizenz-CD in das CD-Laufwerk.
3. Starten Sie nun die uniVision-Software und öffnen Sie ein Projekt (z.B. Beispieldatei) im Offline-Betrieb. Verbinden Sie sich nicht zu einem Gerät.
4. Durch Klicken auf den Menüleisteneintrag „Hilfe“ → „Lizenzen“ öffnet sich das Lizenzfenster.



5. Auf „Laden“ klicken und im Unterordner des CD-Laufwerks die entsprechenden Lizenzdateien auswählen.
6. Die Module, für die die Lizenzen hinzugefügt wurden, werden nun im Lizenzfenster als verfügbar angezeigt und können in Offline-Projekten verwendet werden.



HINWEIS!


Die Nummer der Lizenzdatei muss identisch sein mit der Nummer, die sich auf dem USB-Dongel befindet.

Installation Instructions uniVision offline licenses for decode and pattern match modules


1. Plug the USB dongle into a vacant USB port.



2. Insert the license CD into the CD drive.
3. Start uniVision software and open a project (e.g. sample file) in the offline mode. Do not connect to a device.
4. After clicking “Licenses” under “Help” in the menu bar, the license window appears.



5. Click “Load” and select the corresponding license files from the subdirectory on the CD drive.
6. The modules for which licenses have been added are now displayed as available in the license window and can be used in offline projects.



NOTE!

The license file's number must be identical to the number on the USB dongle.