Dimensions





Model Number

RL28-8-H-2000-IR-3019/47/115b


Background suppression sensor with 0.2 m fixed cable and 4-pin, M12 connector

Features

- Ultra bright LEDs for power on and • switching state
- Minimal black-white difference through the infrared transmission LED
- Not sensitive to ambient light, even • with switched energy saving lamps
- Waterproof, degree of protection IP67 ٠
- Protection class II •


54.3 14.8 M. ø 5.2 -0.2 Emitter 26.5 88 Receive Dovetail mount ø 6. LED indicator: switching state LED indicator switching state LED inc ۲ operation itivity adjuster

Electrical connection





Pinout





Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



 U_B

 I_0

f

protected , open collectors

-40 ... 60 °C (-40 ... 140 °F)

-40 ... 75 °C (-40 ... 167 °F)

according to IEC 60664-1

0.2 m fixed cable with 4-pin, M12 connector

II, rated voltage \leq 250 V AC with pollution degree 1-2

 $\mathsf{E87056}$, cULus Listed , class 2 power supply , type rating 1

max. 30 V DC

max. 200 mA

EN 60947-5-2

250 Hz

25.8 mm

54.3 mm

Plastic ABS

plastic

70 g

88 mm

IP67

2 ms

Technical data

Detection range

Light source

Light type

MTTFd

General specifications

Detection range min.

Detection range max.

Background suppression

Diameter of the light spot

Angle of divergence

Ambient light limit

Mission Time (T_M)

Operation indicator

Function indicator

Control elements

Operating voltage

Ripple

Output Switching type

Signal output

Switching voltage

Switching current

Response time

Product standard Ambient conditions Ambient temperature

Storage temperature

Degree of protection

Approvals and certificates Protection class

Housing height

Housing depth

Connection

Housing Optical face

UL approval

Material

Mass

Mechanical specifications Housing width

Conformity

Switching frequency

Electrical specifications

No-load supply current

Diagnostic Coverage (DC)

Indicators/operating means

Black/White difference (6 %/90 %)

Functional safety related parameters

Accessories **OMH-05** 20 ... 2000 mm Mounting aid for round steel ø 12 mm or 20 ... 200 mm sheet 1.5 mm ... 3 mm 20 ... 2000 mm max. + 10 % of the upper limit of the detection range **OMH-07** IRED Mounting aid for round steel ø 12 mm or modulated infrared light, 880 nm sheet 1.5 mm ... 3 mm < 40 % **OMH-21** approx. 70 mm at a distance of 2000 mm transmitter 2° Mounting bracket receiver 2° 50000 Lux **OMH-22** Mounting bracket 720 a OMH-MLV11-K 20 a dove tail mounting clamp 0% OMH-RLK29-HW LED areen Mounting bracket for rear wall mounting 2 LEDs yellow ON: object inside the scanning range OMH-RL28-C OFF: object outside the scanning range Weld slag cover model Sensing range adjuster Other suitable accessories can be found at 10 ... 30 V DC www.pepperl-fuchs.com 10 % ≤ 40 mA light/dark on 2 PNP, complementary, short-circuit protected, reverse polarity

Date of issue: 2018-03-26 180713_eng.xml Release date: 2018-03-26 09:49

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group USA: +1 330 486 0001

www.pepperl-fuchs.com


2


Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Curves/Diagrams





Additional information

Intended use:

The transmitter and receiver are located in the same housing for direct detection sensors with background masking. Marking of objects outside the detection range is achieved by arranging the angle between the transmitter and receiver (2 receiver elements).

Objects are detected independently of their surface structures, brightness and colour, as well as the brightness of the background.

Mounting instructions:

The sensors can be fastened directly with fixing screws or with a support bracket (not included with delivery).

The surface underneath must be flat to prevent the housing from moving when it is tightened into position. We recommend securing the nut and screw in place with spring washers to prevent the sensor from going out of adjustment.

Adjustment:

After the operating voltage is applied, the LED is lit green.

Align the sensor to the background. If the yellow LED is lit, the detection range should be reduced with the detection range adjuster until the yellow LED goes out.

Object direction:

Place the object to be detected at the desired maximum detection range and align the light spot to it. If the object is detected, the yellow LED lights up.

If it does not light up, the detection range must be adjusted on the potentiometer until it lights up when an object is detected.

Cleaning:

We recommend cleaning the optical surface and checking the screwed connection and other connections at regular intervals.

180713_eng.xml



3