



CE

Model Number

SBL-8-H-900-IR-SL-V-3928

Background suppression sensor with 4-pin, M12 x 1 connector and fixed cable with 4-pin, M12 socket

Features

- Background suppression sensor for roller conveyors
- For installation between the rollers on a roller conveyor
- Very small black-white difference
- Adjustable detection range ٠
- Can be connected in series
- 3 in 1: Sensor, pneumatic valve and integrated control logic


Product information


Sensors of the SBL series are used to easily control material flow on roller conveyors in material handling and other branches.

The SBL series is a precise background suppression sensor according to the 3 element method. The sensor features superior background suppression and a very good ambient light immunity. Material and transport container of all colors and opacities are reliably detected.


The special design allows the sensor to be mounted between the rollers of a roller conveyor or any other conveying unit. Mounting between the rollers is easy and protects the sensor.

Dimensions






Electrical connection






Pinout



Indicators/operating means



	1	Signal display	yellow
	2	Sensing range adjuster	

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



40 ... 900 mm

40 ... 340 mm

40 ... 900 mm

IRED

< 10 %

At 20°C

1100 a

20 a

0%

340 ... 900 mm

standard white 200 mm x 200 mm

modulated infrared light, 880 nm

max. 38 sensors per line

Detection range adjuster

24 V DC ± 20 %

max. 10 %

dark on

100 Hz

5 ms

air

IP65

plastic

plastic lens

directions

approx. 200 g

max. 115 mA

max. 30 V DC max. 200 mA

3/2 way valve

currentless closed

4 ... 7 bar (58 ... 101.5 psi)

-15 ... 50 °C (5 ... 122 °F) -30 ... 60 °C (-22 ... 140 °F)

straight M12 x 1 ; Length: 1930 mm

EMC Directive 2004/108/EC

approx. 60 mm at detection range 900 mm

LED yellow: lights when object is detected

continuous light 30000 Lux, Fluorescent lamp 5000 Lux

1 PNP, short-circuit protected, reverse polarity protected

4-pin, M12 x 1 connector ; Connecting cable with Socket,

IEC / EN 60068. half-sine, 40 g in each X, Y and Z directions IEC / EN 60068-2-6. Sinus. 10 -1000 Hz, 10 g in each X, Y and Z

Technical data General specifications Detection range Detection range min. Detection range max Adjustment range Reference target Light source Light type Black/White difference (6 %/90 %) Diameter of the light spot Cascadability Ambient light limit Functional safety related parameters $\mathsf{MTTF}_{\mathsf{d}}$ Mission Time (T_M) Diagnostic Coverage (DC) Indicators/operating means Function indicator Control elements **Electrical specifications** Operating voltage U_B Ripple No-load supply current I_0 Output Switching type Signal output Switching voltage Switching current Switching frequency f Response time Pneumatic output Type of valve Operating pressure Medium Ambient conditions Ambient temperature Storage temperature Mechanical specifications Protection degree Connection Material Housing

Optical face Compliance with standards and directi-Directive conformity

Mass

ves

Standard conformity Product standard Shock and impact resistance Vibration resistance

Approvals and certificates

UL approval cULus Listed, Class 2 Power Source, Type 1 enclosure CCC approval CCC approval / marking not required for products rated ≤36 V

EN 60947-5-2:2007

IEC 60947-5-2:2007

OMH-SBL-01 Mounting bracket for sensors of SBL series

V1-G-2M-PVC Female cordset, M12, 4-pin, PVC cable

V1-G-5M-PVC Female cordset, M12, 4-pin, PVC cable

V1-W-2M-PUR Female cordset, M12, 4-pin, PUR cable

V1-W-5M-PUR Female cordset, M12, 4-pin, PUR cable

V1S-TEE-V1/V1S T-Distributor, M12 connector to M12 socket/connector

Schraubendreher 0,5 x 3,0 mm Screwdriver

Additional accessories can be found in the Internet.


Pepperl+Fuchs Group www.pepperl-fuchs.com

2

Germany: +49 621 776 4411



Curves/Diagrams



Options:

Sensors with the version -V are equipped with a solenoid valve and can directly control a 3/2 way pneumatic actuator, without any-interaction of an external system controlling unit (PLC). As soon as conveyed goods are detected, the diffuse mode sensor gives an electrical-signal to the pneumatic solenoid valve, which is then activated.

Sensors with the control logic option -SL-(V) allows up to 50 diffuse mode sensors to be connected-to each other (data and power), depending on the current consumption of sensor and solenoid valve. An additional supply power and data bus cable is used to interconnect the sensors with control logic option -SL. All necessary functions for controlling the material flow of conveyed goods are supported, such as: single feed, single release, slug release, external motor and solenoid valve control. It is also possible to energize the valves of all sensors included in the cascade by slug release (VT). To do this, apply the positive supply voltage (+UB) on the input VT of the first sensor.

Sensors with timing function -Z features the adjustment of the ON- and OFF delay of the output independently. This optimizes control of the solenoid valve. A zero pressure accumulation of the conveyed goods can be realized with application of time ONand OFF delay of the output. The ON- and OFF delay to control the switching of the solenoid valve may be adjusted between 0 and 2 seconds.

Additional power supply between every 20 to 25 sensors can be realized by the use of the power in feed junction V1S-TEE-V1/ V1S in combination with a cable V1-G-...-PVC. This features to practically connect any number of SBL sensors in series. Attention should be paid to the maximum rated current of the cable and the connectors which usually is max. I = 4 A. For more details on the maximum rated current of single components, please refer to our datasheet values. For the electrical supply of the sensors the country specific standards have to be considered.

Note:

Pepperl+Fuchs Group www.pepperl-fuchs.com

Use a screwdriver to adjust the sensing range. We strongly recommend to use the screwdriver given in the accessories section.

