## Features

- 4-channel
- Inputs Ex ia
- Installation in suitable enclosures in Zone 1
- Module can be exchanged under voltage (hot swap)
- Power supply for 2-wire transmitters with 4 mA ... 20 mA
- Supply circuit 15 V (20 mA)
- · Input from active signals of 4-wire transmitters
- Simulation mode for service operations (forcing)
- Line fault detection (LFD): one LED per channel
- Permanently self-monitoring

## **Function**


The transmitter power supply feeds 2- and 3-wire transmitters. Active signals from separately powered field devices and 4-

wire transmitters can be connected.

Open and short-circuit line faults are detected.

The intrinsically safe inputs are galvanically isolated from the bus and the power supply.


## Assembly



CE



## Connection



Pepperl+Fuchs Group U www.pepperl-fuchs.com pa-inf

USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com

Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com



Slots	
Occupied slots	2
Supply	
Connection	backplane bus
Rated voltage U <sub>r</sub>	12 V DC , only in connection with the power supplies FB92**
Power dissipation	1.5 W
Power consumption	2.7 W
Internal bus	
Connection	backplane bus
Interface	manufacturer-specific bus to standard com unit
Analog input	
Number of channels	4
Suitable field devices	4
Field device	pressure converter
Field device [2]	flow converter
Field device [3]	level converter
Field device [4]	Temperature Converter
Field device interface	
Connection	2-wire transmitter
Connection [2]	3-wire transmitter
Connection [3]	4-wire transmitter
Connection	2-wire transmitter: supply circuit: channel I 1+, 2-, channel II 5+, 6-, channel III 9+, 10-, channel IV 13+, 14- 3-wire transmitter: supply circuit: channel I 1+, 4-, channel II 5+, 8-, channel III 9+, 12-, channel IV 13+, 16- measuring circuit: channel I 3+, 4-, channel II 7+, 8-, channel III 11+, 12-, channel IV 15+, 16- 4-wire transmitter (separately powered): measuring circuit: channel I 3+, 4-, channel II 7+, 8-, channel III 11+, 12-, channel IV 15+, 16-
Transmitter supply voltage	$\geq$ 15 V at 20 mA; 21.5 V at 4 mA
Input resistance	$15\Omega$
Conversion time	≤ 100 ms
Line fault detection	can be switched on/off for each channel via configuration tool, configurable via configuration tool
Short-circuit	factory setting: > 22 mA configurable between 0 26 mA
Open-circuit	factory setting: < 1 mA configurable between 0 26 mA
HART communication	
HART secondary variable	no
Analog output	
HART communication	no
HART secondary variable	no
Transfer characteristics	
Deviation	
After calibration	0.1 % of the signal range at 20 °C (68 °F)
Influence of ambient temperature	0.1 %/10 K of the signal range
Resolution	12 Bit (0 26 mA)
Refresh time Indicators/settings	100 ms
LED indication	Power LED (P) green: supply Diagnostic LED (I) red: module fault, red flashing: communication error, white: fixed parameter set (parameters from com unit are ignored), white flashing: requests parameters from com unit Status LED (1-4) red: line fault (lead breakage or short circuit)
Coding	optional mechanical coding via front socket
Directive conformity	
Electromagnetic compatibility	
Directive 2014/30/EU	EN 61326-1:2006
Conformity	
Electromagnetic compatibility	NE 21:2007
Degree of protection	IEC 60529:2000
Environmental test	EN 60068-2-14:2009
LINIOIIIIEIIlai lesi	EN 60068-2-27:2009
Shock resistance	EN 00008-2-27.2009
	EN 60068-2-6:2008
Shock resistance Vibration resistance	
Shock resistance Vibration resistance Damaging gas	EN 60068-2-6:2008 EN 60068-2-42:2003
Shock resistance Vibration resistance Damaging gas Relative humidity	EN 60068-2-6:2008
Shock resistance Vibration resistance Damaging gas Relative humidity Ambient conditions	EN 60068-2-6:2008 EN 60068-2-42:2003 EN 60068-2-78:2001
Shock resistance Vibration resistance Damaging gas Relative humidity	EN 60068-2-6:2008 EN 60068-2-42:2003

Refer to "General Notes Relating to Pepperl+Fuchs Product Information". Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com

Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com



Charle registeres		sheet time Labor duration 11 me sheet amplitude 15 g, number of sheets 19
Shock resistance Vibration resistance		shock type I, shock duration 11 ms, shock amplitude 15 g, number of shocks 18 frequency range 10 150 Hz; transition frequency: 57.56 Hz, amplitude/acceleration ± 0.075 mm/1 g; 10
Vibration resistance		cvcles
		frequency range 5 100 Hz; transition frequency: 13.2 Hz amplitude/acceleration ± 1 mm/0.7 g; 90 minutes at each resonance
Damaging gas		designed for operation in environmental conditions acc. to ISA-S71.04-1985, severity level G3
Mechanical specifications		
Degree of protection		IP20 (module), a separate housing is required acc. to the system description
Connection		removable front connector with screw flange (accessory) wiring connection via spring terminals (0.14 1.5 mm <sup>2</sup> ) or screw terminals (0.08 1.5 mm <sup>2</sup> )
Mass		approx. 750 g
Dimensions		57 x 107 x 132 mm (2.2 x 4.2 x 5.2 inch)
Data for application in co with hazardous areas	nnection	
EU-Type Examination Certi	ficate	BVS 12 ATEX E 101 X
Marking		<ul> <li>(₺) II 2(1) G Ex d [ia Ga] IIC T4 Gb</li> <li>(₺) II (1) D [Ex ia Da] IIIC</li> </ul>
Supply		
Voltage	Uo	27 V
Current	I <sub>o</sub>	90 mA
Power	Po	588 mW (linear characteristic)
Input		
Voltage	Uo	0.7 V
Current	Ι <sub>ο</sub>	2.78 mA
Power	Po	2 mW (trapezoid characteristic curve)
Internal capacitance	Ci	242 nF
Internal inductance	Li	0 mH
Galvanic isolation		
Input/power supply, internal bus		safe electrical isolation acc. to EN 60079-11:2007 , voltage peak value 375 V
Directive conformity		
Directive 2014/34/EU		EN 60079-0:2009 EN 60079-1:2007 EN 60079-11:2012 EN 60079-26:2007
International approvals		
ATEX approval		BVS 12 ATEX E 101 X
INMETRO		Brazil: TÜV 14.1597X
Marine approval		
Bureau Veritas Marine		22449/B0 BV
General information		
System information		The module has to be mounted in appropriate backplanes and housings (FB92**) in Zone 1, 2, 21, 22 or outside hazardous areas (gas or dust). Here, observe the corresponding EC-type examination certificate.
Supplementary information		EC-Type Examination Certificate, Statement of Conformity, Declaration of Conformity, Attestation of Conformity and instructions have to be observed where applicable. For information see www.pepperl-fuchs.com.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com

Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com

