

Model Number

MLV41-LL-RT-IO/92/136

Fiber optic sensor

with 4-pin, M12 x 1 connector

Features

CE

- Robust fiber optic sensor for reliable operation under all conditions
- Adjustable continuous sensitivity
- Easy fiber optic installation with quick-٠ action clamping lock
- Aluminum housing with high-quality Delta Seal coating
- IO-link interface for service and pro-٠ cess data

Product information

The unique and extremely popular design of the MLV41 series enables it be mounted correctly in confined areas and offers all the functions that are normally only found on larger phototelectric sensors. The MLV41 series comes with a range of functions. For example, highly visible status LEDs on the front and back, resistance to ambient light, crosstalk protection and universally applicable output stages that permit every possible switching logic and polarity to be realized. The enhanced resistance to ambient light ensures reliable operation even where modern energy-saving lamps with electronic ballasts are in use. The same applies where multiple devices are present, i.e. the use of a number of sensors in the same vicinity causes no problems.







Electrical connection

30.5

13.6

M12x1

Option:





Pinout



Indicators/operating means



USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Technical data		Accessories
General specifications		
Sensor range	on black (6 %): up to 36 mm on Kodak white, reflection factor 90% up to 120 mm with LLR 04-1.6-0.5-WC3 fiberoptic cable	Software for the integration of IODDs in a frame application (e. g. PACTware)
Adjustment range	0 120 mm on Kodak white, reflection factor 90%	IO-I ink-Master02-USB
Reference target	100 mm x 100 mm on Kodak white, reflection factor 90%	IO-Link master supply via USB port or se-
Light source		parate power supply 1 ED indicators M12
Light type	modulated visible red light , 660 nm	plug for sensor connection
MTTE.	770 a	
Mission Time (T _M)	20 a	OMH-41
Diagnostic Coverage (DC)	0%	Mounting bracket
Indicators/operating means		V1-G-2M-PUB
Operation indicator	LED green, statically lit Power on , Undervoltage indicator: Green LED, pulsing (approx. 0.8 Hz) , short-circuit : LED gre flashing (approx. 4 Hz) , IO link communication: green LED goes out briefly (1 Hz)	Female cordset, M12, 4-pin, PUR cable
Function indicator	LED yellow, lights up with receiver lit ; flashes when falling s of the stability control	hort Female cordset, M12, 4-pin, PUR cable
Control elements	sensitivity adjustment	Class fiber antia diffuse with BVC as
Electrical specifications		Vering
Operating voltage	U _B 1030 V DC	venng
Ripple	max. 10 %	LLR 04-1,6-0,5-G(M6x30)
Interface	1 ₀ max. 40 mA	Glass fiber optic - diffuse with metal silico-
Interface	IQ-1 ink	ne covering
Protocol	IQ-Link	LCB 04-1 6-0 5-WC 3
Mode	COM 2 (38.4 kBaud)	Glass fiber ontic - diffuse with PVC on
Output		Vering
Switching type	light/dark on	Vernig
Signal output	2 push-pull (4 in 1) outputs, complementary, short-circuit pro	LLR 04-1,6-0,5-W C3Doof,Glass fiber optic - diffuse with metal silico-
Switching voltage	max. 30 V DC	ne covering
Switching current	max. 100 mA	LCE 04-1,6-1,0-Z1
Voltage drop	$U_{d} \leq 2.5 \text{ V DC}$	Glass fiber optic - thru-beam with PVC co-
Switching frequency	f 1000 Hz	vering
Response time	0.5 ms	
Ambient conditions	00 00 %0 / 4 140 %5	LCE 04-1,6-1,0 G
Storage temperature	-20 60 C (-4 140 P) -40 75 °C (-40 167 °F)	Glass fiber optic - thru-beam with PVC co-
Mechanical specifications		vering
Housing width	31 mm	LLE 04-1,6-1,0-G
Housing height	56.5 mm	Glass fiber optic - thru-beam with metal si- licone covering
Housing depth	13.6 mm	
Fiber optic adapter	04	LCE 04-1 6-1 0-W C3
Degree of protection	IP67	Glass fiber ontic - thru-beam with PVC co-
Connection	4-pin, M12 x 1 connector	Vering
Housing	Aluminum . Delta-Seal coated	voinig
Optical face	Fiber optic connection	LLE 04-1,6-1,0-W C3
Connector	metal	Glass fiber optic - thru-beam with metal si- licone covering
Mass	50 g	
Compliance with standards and d	lirecti-	MLV41-LL IODD
Ves Directive conformity		IODD for communication with MLV41-LL-
EMC Directive 2004/108/FC	EN 60947-5-2:2007	IO-Link sensors
Standard conformity		
Product standard	EN 60947-5-2:2007 IEC 60947-5-2:2007	other suitable accessories can be found at www.pepperl-fuchs.com
Approvals and certificates		
Protection class	II, rated voltage ≤ 50 V AC with pollution degree 1-2 accord to IEC 60664-1 functional insulation acc. to DIN EN 50178	ling
UL approval	cULus Listed 57M3 (Only in association with UL Class 2 po supply; Type 1 enclosure)	wer
CCC approval	CCC approval / marking not required for products rated ≤3	6 V
IO link function		
The IO link operating mode is ir $(f = 1 Hz)$. IO link communicatio from the sensor) and access to react the requirement data contains the Identification: • Manufacturer information	ndicated by the green LED indicator with a short interrup n simultaneously provides process data (measurement o equirement data. ne following information:	tion lata

Identification:

2

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



- Product ID
- · User-specific ID
- **Device parameters:**
- Teach-in parameters
- Operating parameters
- Configuration parameters
- · Device commands
- Diagnostic messages and warnings

Setting information

Detection range adjustment:

The detection range can be set via the rotary switch or the IO-Link.

Setting using the rotary switch:

If you would like to change the detection range on the sensor, turn:

- the rotary switch to the left to reduce the value.
- the rotary switch to the right to increase the value.

With the IO-Link, the set detection range the current rotary switch configuration is always assigned. If the rotary switch is too far to the left or the right, perform the following:

Turn the potentiometer completely to the left until it stops. The LED will briefly flash green. The assignment of the current rotary switch configuration to the detection range set via IO-Link is overridden. Now set the desired detection range again.

Example application - manually reduce detection range:



The potentiometer has one position as shown here. The adjustable detection range is set via IO-Link to maximum. The rotary switch is too far to the left to set a considerably lower detection range for example.



Turn the potentiometer to the left until it stops to override the set value to this rotary switch configuration. The LED will briefly flash green.



Now set the desired detection range again.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

