Features

- 1-channel
- Analog output module for 0/4 mA ... 20 mA
- Installation in Zone 2 or safe area
- · HART communication via field bus or service bus
- Simulation mode for service operations (forcing)
- Line fault detection (LFD)
- · Permanently self-monitoring
- Module can be exchanged under voltage


Function

The device drives positioners, proportional valves, I/P converters, or local indicators.

Open and short circuit line faults are detected.


The output is galvanically isolated from the bus and the power supply.

Assembly





Connection



Zone 2

Slots	
Occupied slots	1
Supply	
Connection	backplane bus
Rated voltage U _r	12 V DC, only in connection with the power supplies LB9***
Power dissipation	0.8 W
Power consumption	0.95 W
Internal bus	
Connection	backplane bus
Interface	manufacturer-specific bus to standard com unit
Analog output	
Number of channels	1
Suitable field devices	
Field device	Proportional Valve
Field device [2]	I/P converters
Field device [3]	on-site display
Connection	channel I: 2/3+, 4/5-
Current	0 25 mA short-circuit protected
Line fault detection	can be switched on/off for each channel via configuration tool, configurable via configuration tool
Short-circuit	factory setting: < 50 Ω configurable between 0 26 mA
Open-circuit	deviation of preset output value > 0.5 mA
Load	750 Ω max.
HART communication	yes
HART secondary variable	MODBUS: yes; all other bus systems: no
Watchdog	within 0.5 s the device goes in safe state, e.g. after loss of communication
Transfer characteristics	
Deviation	
After calibration	0.1 % of the signal range at 20 °C (68 °F)
Influence of ambient temperature	0.1 %/10 K of the signal range
Refresh time	100 ms
Indicators/settings	
LED indication	Power LED (P) green: supply
	Diagnostic LED (I) red: module fault, red flashing: communication error, white: fixed parameter set (parameters from com unit are ignored), white flashing: requests parameters from com unit Status LED (1) red: line fault (lead breakage or short circuit)
Coding	optional mechanical coding via front socket
Directive conformity	
Electromagnetic compatibility	
Directive 2014/30/EU	EN 61326-1:2006
Conformity	
Electromagnetic compatibility	NE 21:2007
Degree of protection	IEC 60529:2000
Environmental test	EN 60068-2-14:2009
Shock resistance	EN 60068-2-27:2009
Vibration resistance	EN 60068-2-6:2008
Damaging gas	EN 60068-2-42:2003
Relative humidity	EN 60068-2-78:2001
Ambient conditions	
Ambient temperature	-20 60 °C (-4 140 °F) , 70 °C (non-Ex)
Storage temperature	-25 85 °C (-13 185 °F)
Relative humidity	95 % non-condensing
Shock resistance	shock type I, shock duration 11 ms, shock amplitude 15 g, number of shocks 18
Vibration resistance	frequency range 10 150 Hz; transition frequency: 57.56 Hz, amplitude/acceleration ± 0.075 mm/1 g; 10 cycles frequency range 5 100 Hz; transition frequency: 13.2 Hz amplitude/acceleration ± 1 mm/0.7 g; 90 minutes at
	each resonance
Damaging gas	designed for operation in environmental conditions acc. to ISA-S71.04-1985, severity level G3
Mechanical specifications	
Degree of protection	IP20 when mounted on backplane
Connection	removable front connector with screw flange (accessory) wiring connection via spring terminals (0.14 1.5 mm²) or screw terminals (0.08 1.5 mm²)
Mass	approx. 90 g
Dimensions Data for application in connection with hazardous areas	16 x 100 x 102 mm (0.63 x 3.9 x 4 inch)
Certificate	BVS 12 ATEX E 115 X



Marking	⟨ि II 3 G Ex nA [ic] IIC T4 Gc
Galvanic isolation	
Output/power supply, internal bus	safe electrical isolation acc. to EN 60079-11, voltage peak value 375 V
Directive conformity	
Directive 2014/34/EU	EN 60079-0:2009 EN 60079-11:2007 EN 60079-15:2010
International approvals	
ATEX approval	BVS 12 ATEX E 115 X
IECEx approval	BVS 11.0068X
Approved for	Ex nAc [ic] IIC T4
Marine approval	
Lloyd Register	15/20021
Bureau Veritas Marine	22449/B0 BV
General information	
System information	The module has to be mounted in appropriate backplanes (LB9***) in Zone 2 or outside hazardous areas. Here, observe the corresponding declaration of conformity. For use in hazardous areas (e. g. Zone 2 or Zone 22) the module must be installed in an appropriate enclosure.
Supplementary information	EC-Type Examination Certificate, Statement of Conformity, Declaration of Conformity, Attestation of Conformity and instructions have to be observed where applicable. For information see www.pepperlfuchs.com.

