





Model Number

UC400-F77-IU-IO-0.2M-V1


Single head system

Features

- **IO-Link interface for** parameterization
- Programmable via DTM with **PACTWARE**
- Selectable sound lobe width
- Synchronization options
- **Temperature compensation**
- **Analog output**

Diagrams

Characteristic response curve





Date of issue: 2018-07-25

Release date: 2018-07-25 15:49



Technical data

C	General specifications			
	Sensing range	30 400 mm		
	Adjustment range	40 400 mm		
	Dead band	0 30 mm		
	Standard target plate	20 mm x 20 mm		
	Transducer frequency	approx. 310 kHz		
	Response delay	minimum: 10 ms		
		factory setting: 37 ms		
	Sensor cycle time	≥ 10 ms (factory setting);		

programmable to 60 s

Memory Non-volatile memory EEPROM

Write cycles 300000

Indicators/operating means LED green solid: power on

flashing: standby mode or IO-Link communication LED yellow solid: object in evaluation range

flashing: programming of the limits, object detected LED red solid: fault

flashing: programming limits, object not detected

18 ... 30 V DC , ripple 10 %SS Operating voltage UB

No-load supply current I₀ ≤ 50 mA Power consumption P₀ \leq 500 mW Time delay before availability ty < 300 ms

Interface

IO-Link (after individual activation via programming button Interface type

Input/Output Input/output type

Electrical specifications

0 Level 0 ... 1 V 2.5 V ... U_B 1 Level Input impedance $> 22 k\Omega$

Output rated operating current current sink < 35 mA

≥ 1 ms with external control, low active Pulse length Synchronization frequency

Common mode operation < 109 Hz

Multiplex operation $\leq 109~Hz~/~n$, n = number of sensors , $n \leq 10$

Output

Output type 1 analog output 0 (4) ... 20 mA or

1 analog output 0 ... 10 V

Resolution current output: evaluation range [mm]/3200 but ≥ 0.35 mm

voltage output: evaluation range [mm]/4000 but \geq 0.35 mm

1 synchronization connection, bidirectional

Deviation of the characteristic curve ≤±1 % of full-scale value ≤ ± 0.1 % of full-scale value Repeat accuracy current output: ≤ 500 Ohm Load impedance

voltage output: ≥ 1000 Ohm Temperature influence $\leq \pm 0.75$ % of the end value (with temperature compensation)

from 10 minutes after switching on the sensor; 0,17 %/K

(without temperature compensation)

Ambient conditions

current output -25 ... 60 °C (-13 ... 140 °F) voltage output -25 Ambient temperature

... 70 °C (-13 ... 158 °F)

-40 ... 85 °C (-40 ... 185 °F) Storage temperature

Mechanical specifications

Connection type Cable connector M12 x 1 , 4-pin , L = 200 mm

Degree of protection IP67

Material

Housing Polycarbonate Transducer

epoxy resin/hollow glass sphere mixture; polyurethane foam

any position Installation position 20.5 g

Tightening torque, fastening screws max. 0.2 Nm

Factory settings

Output near limit: 40 mm far limit: 400 mm

Output mode: rising ramp output type: 4 ... 20 mA

Beam width wide

Compliance with standards and directives

Standard conformity

Standards EN 60947-5-2:2007+A1:2012


IEC 60947-5-2:2007 + A1:2012 EN 60947-5-7:2003

IEC 60947-5-7:2003


Approvals and certificates **UL** approval cULus Listed, Class 2 Power Source

CCC approval CCC approval / marking not required for products rated ≤36 V

Dimensions



Electrical Connection




Pinout



Additional Information

Analog output modes



FPEPPERL+FUCHS

Wire colors in accordance with EN 60947-5-2

1	BN	(brown)
2	WH	(white)
3	BU	(blue)
4	BK	(black)

Accessories

IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

V15-G-2M-PVC

Female cordset, M12, 5-pin, PVC cable

V1-G-1M-PVC-V1-G

Connecting cable, M12 to M12, PVC cable 4-pin

OMH-ML7-01

Mounting aid for ML7 and ML8 series, Mounting bracket

OMH-ML7-02

Mounting aid for ML7 and ML8 series, Mounting bracket

Description of Sensor Functions

Adjustment possibilities

The sensor features an analog output with 2 programmable limits. Programming the limits, the output mode, the output type and the beam width can be done in two different ways:

- Using the sensor's programming button
- Using the IO-link interface of the sensor. This method requires an IO-link master (e.g. IO-link-Master02-USB) and the associated software. The download link is available on the product page for the sensor at www.pepperl-fuchs.de

Synchronization

The sensor features a synchronization input for suppressing ultrasonic mutual interference ("cross talk").

The following synchronization modes are available:

- 1. Automatic multiplex mode.
- 2. Automatic common mode
- 3. Externally controlled synchronization

Further Documentation

- For information on programming via programming button and synchronisation you may refer to the commissioning instruction.
- For detailed information on application and programming via IO-Link we provide a manual.