

# CE

## **Model Number**

#### DoorScan-I

Sensor module, interface

## Features

- ٠ Sensor module for configurable Door-Scan® presence sensor
- Multi-function interface with full operation
- ٠ Complete system supply for the entire system for one door
- ٠ Can also be used to supply the emitter and receiver modules with power
- Single button commissioning with automatic Teach-in function
- SIL 2, certified in accordance with DIN • 18650/EN 16005
- Tool-free module mounting using ٠ snap-in mechanism
- Switchable NPN or PNP outputs ٠





# **Electrical connection**

Dimensions



## Indicators/operating means



8 Jumper

9 Teach button

- 3 Status LED, red
- 4 Blank LED, green
- 5 DIP LEDs, green

Pepperl+Fuchs Group www.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Technical data	Accessories	
General specifications	DoorScan Cable BS/BGS	
Operating mode	Background evaluation	Connecting cable for transition from binge
Functional safety related parameter		
Safety Integrity Level (SIL)	SIL 2	side to leading edge side
Performance level (PL)	PL d	DoorScan Transfer Loop
Category	Cat. 2	Door transition cable to door controller for
MTTFd	2716 a	DoorScan® sensor including cable she-
Mission Time (T <sub>M</sub> )	20 a	athing and strain relief
Diagnostic Coverage (DC)	90 %	at ing and strain relief
Indicators/operating means		DoorScan Connection Cable 5p
Function indicator	Interface: Red LED: detection, excess gain, fault code Yellow LED: teach status Green LED: blank status Green LED: DIP switch status	Connecting cable with 5 plug-in connec- tions for DoorScan®-I/-T/-R modules
Electrical specifications	Adapter module for installation in the	
Operating voltage	U <sub>B</sub> 24 V DC +/- 20 %	Adapter module for installation in the
No-load supply current	l <sub>o</sub> 30 mA	DoorScan® and TopScan sensor profile,
Input		multifunction interface module
Test input	high level $\geq$ 15 V low level $\leq$ 2 V	DoorScan Cable Adapter
Control input	Standby active at U = 11 V DC at 30 V DC	Adapter module for installation in the
Output	,	
Switching type	light on	interface module
Signal output	switchable NPN or PNP , short-circuit protected	Other suitable accessories can be found at
Switching voltage	max. 30 V DC	
Switching current	max. 100 mA	www.peppen-lucits.com
Response time	≤ 52 ms	
	$\leq$ 200 ms in boost operating mode	
Ambient conditions		
Ambient temperature	-30 60 °C (-22 140 °F)	
Mechanical specifications		
Mounting height	max. 3500 mm	
Degree of protection	IP54 (iwhen mounted)	
Connection	plug strip , 6-pin	
Mass	approx. 30 g	
Compliance with standards and dives	irecti-	
Directive conformity		
Machinery Directive 2006/42/EC	EN 12978:2003+A1:2009 EN ISO 13849-1:2008 + AC:2009 EN 16005:2012 Chapter 4.6.8	
EMC Directive 2004/108/EC	EN 61000-6-2:2005 EN 61000-6-3:2007+A1:2011	
Standard conformity		
Standards	EN 61508-1:2010 DIN 18650-1:2010 Chapter 5.7.4 BS 7036-1:1996 Chapter 7.3.2 BS 7036-2:1996 Chapter 8.1	
Approvals and certificates		
	CCC approval / marking not required for products rat	

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group USA: +1 330 486 0001

www.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



2

## **Additional Information**

Layout of the sensor system for a door (door hinge side/hinge opposite side)



#### Standby

When the supply voltage is applied, the sensor is put into standby; the energy consumption is reduced to less than 80% in this state. Once the signal is deactivated, the sensor is immediately ready for operation and enables the signal outputs within 52 ms and/or 200 ms (in boost operating mode) if the detection field is free.



## **Test input circuit**

#### DoorScan test input circuit

Test Function	Test inactive	Test active	Interface, bottom row, Dip switch 1 and 2
High active	Herein Controller DoorScan Interface GND or open.	+24 V Controller DoorScan Interface	
Low active	+24 V Controller	+24 V Controller A or open Test input	ON 1 2
High inactive	+24 V Controller Interface	+24 V Controller DoorScan Interface	ON 1 2
Low inactive	Controller DoorScan Interface Test input	Controller DoorScan Interface Test input	

#### **Test signal**

The signal outputs enable crossed circuit detection. To do so, the outputs carry out a delayed shutoff from each other (see signal curve).

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com





The duration of the test signal must not exceed 0.5 s, otherwise this will deactivate the sensor.

## **Operating modes**

Boost operating mode

Activation with dark floors, even at high installation heights (increased sensitivity). In these cases, the response time of the sensor is increased from 50 ms to 200 ms. If necessary, the speed of the door must be adjusted to the response time.

#### Grid operating mode

Activation in the event of faults due to metal grating on the ground. Used where metal grating and shafts are present in the detection field.

#### BEAM

Off: outer beams normal

On: outer beams at an angle (factory setting)

You can switch off the beams extending beyond the emitter modules manually to avoid detection of deep door jambs.

#### WALL

Off: automatic wall suppression not active

On: automatic wall suppression active (factory setting)

If the door panel does not open against a wall, you can switch off wall suppression to accelerate the commissioning process. Metal grating mode is improved if receiver modules are used from device version V.03 onward.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"



4