

Technical data	
General specifications	
Description	Hardware diagnostics: Serial numbers, software IDs, etc. Device-specific parameters AS-Interface diagnostics: Detection of short circuits to ground, double addresses, and interference voltage. Measurement of the AS-Interface voltage and currents. Error counter Access to error history in the master. Safety diagnostics: Safety status Display of test requirements and safety-related faults Instructions and recommendations.
System requirements	
Hardware requirements	500 MB of hard disk space available Min. 256 MB working memory
Operating system	Microsoft Windows XP Microsoft Windows 7 (32 and 64 Bit) Microsoft Windows 8 (32 and 64 Bit)

## Model number

### **VAZ-SW-DIAGNOSTIC**

Software for diagnostics, servicing, and final measurement of AS-Interface installations for all K20 and K30-type masters

#### Features

- Intuitive user interface ٠
- Diagnostics and fault correction in • machinery and plant engineering applications
- Includes VAZ-SW-ACT32 AS-Inter-• face software

# Accessories

VAZ-SIMON+-R2-1,8M-PS/2 Interface cable for connecting the K30/K31 Safety Monitor to a PC

#### **VAZ-SIMON-USB**

USB Type A to Micro-USB connector

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

PEPPERL+FUCHS



**VAZ-SW-DIAGNOSTIC**